


3 Enjoy your new outdoor seating set.




Model: _____

Lot No: _____

Date of Purchase: _____

4 PC SET



ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free, customer service number and have this assembly manual open to the parts list ready to provide the model name, number and part name or number.




WARNING: This product may contain small components, please ensure they are kept away from small children.


PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.


2 SEATER



A. Back Cushion
2x




B. Seat Cushion
2x



C. Sofa
1x


CHAIR



D. Back Cushion
2x




E. Seat Cushion
2x



F. Chair
2x

TABLE




G. Table
1x

ASSEMBLY INSTRUCTIONS

Do not fully tighten bolts until assembly is complete.

1 Place the Back Cushions (A) along with the Seat Cushions (B) on the Sofa Frame (C).



2 Place the Back Cushions (D) along with the Seat Cushions (E) on the Chair Frame (F).

