

WARNING!!

Furniture Tipping Risk.

Serious risk of severe or fatal crush injuries can occur from furniture tipping over if not secured.

Children like to climb on furniture and Unsecured furniture can pose a serious danger.

Please follow all instructions and install the tip-over restraints provided.

In addition to installing the restraints, to help prevent tip-over:


- 1. Place heaviest items in the lowest drawers,**
- 2. Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product,**
- 3. Never allow children to climb or hang on drawers, doors, or shelves,**
- 4. Do not leave drawers open,**
- 5. Never open more than one drawer at a time, and**
- 6. Do not step on the base.**

Assembly Instructions

3 DRAWER DRESSER

Caution : You must read this Assembly Instructions before you proceed.


Please look under the cabinet for hardware pack.



CAUTION : This Dresser is NOT a TOY. Keep your child / children at bay in the process of assembly.







For turning / flipping the Dresser and to prevent damage to the dresser, 02 persons may be needed to execute this action.

Parts List

No.	Picture	Description	Qty
A		Cabinet	1
B		Leg	4


Hardware

Dresser Restraint Device Hardware

①		Self Tapping Screws (M4x 20mm)	3
②		Self Tapping Screws (M5x 40mm)	3
③		L-shape Metal Brackets	4
④		Nighstand Restraint Strap	2
⑤		Plastic Anchor (5F)	2
⑥		Bolt (M6 x 100 mm)	5
⑦		Allen Wrench (K4)	2
⑧		Screwdriver (not provided)	1
⑨		Power Drill (not provided)	1
⑩		Hammer (not provided)	1

Assembly Preparation

Before Beginning Assembly:



Read instructions, cover to cover.



Have 2 adults on hand for assembly.



Do not assemble on flooring or carpet.




Assemble on a clean non-marring surface (packing foam).



Save all packaging until finished.


Assembly Steps

OVERVIEW



This Dresser has multiple parts and may require up to 45 minutes to assemble. To give you an overview of the Dresser parts, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise yourself with the parts and steps before assembly.


Step 1



Unpack and place all parts on a clean, non-marring surface.

In the next step, you'll need to lay the Cabinet down to assemble. To avoid any possible risk to the user, please remove the Drawers from the Cabinet.


Step 2




With assistance from your adult partner, carefully lay the Cabinet (A) down with the opening facing up on a clean, non-marring surface as shown above.

Attach the Legs (B) to the Cabinet (A) using Bolts (⑥) and the Allen Wrench (⑦) as shown above.

Step 3



Step 3.1





Step 3.2

Step 3.1: Using a Philips Screwdriver (Not Provided), take the Handles, which can be found in the Drawer.

Step 3.2: To affix the Drawer handles, align the positioning of the Bolts and Handles to the mounting positions of Drawer.

Insert the Bolts through the mounting positions and affix the Handle using a Philips Screwdriver (Not Provided), as shown in the above picture.

Step 4



Put the Drawers into the Dresser.

Ensure that all bolts and handles are fully driven in and locked.

The Dresser is now ready to be used.


Caution: This Dresser can only be used on a flat, level surface.

Dresser Restraint Device Installation Instruction




WARNING

Serious or fatal crushing injuries can occur from tipping furniture.
To help prevent tip-over: **ALWAYS** secure this furniture to the wall
using a Dresser Restraint Device.
See product instructions for more ways to help prevent furniture tip-overs.



Usage For Dresser Restraint Device :

To secure the Dresser against the wall, affix 2pcs Metal Brackets (③) to the wall and 2pcs Metal Brackets (③) to the Dresser. Then, use the Dresser Restraint Strap (④) to connect the Metal Brackets (③) on the wall to the Metal Brackets (③) on the Dresser. Find details as below:




A: Turn the Dresser around as shown above.

Then affix one Metal Bracket (③) to the back of the Dresser using the 2.0cm Self Tapping Screws (①) and Screwdriver (⑧) (not provided).

The distance of the screw mounting positions to the two edges is about 1".

Repeat this step to affix another Metal Bracket (③) to the Dresser, as shown above.



B : Determine the location where the screws should be inserted into the wall.


First, mark the point at the same height on the wall as the L-shaped Metal Bracket (③) on the Dresser. Here are two helpful ways to find these points:

1. Move the Dresser back against the wall, and mark the wall, ensuring the points on the wall are at the same height as the metal brackets on the Dresser.

2. Using a ruler, measure the height from the floor to the Metal Bracket (③) on the Dresser and then measure the same height from the floor up the wall, and mark the wall at that same height.

Using a Power Drill(⑨)(not provided), drill a hole in the wall, then insert a Plastic Anchor (⑤) into the hole using a Hammer(⑩) (not provided).

Repeat this step to affix the other Plastic Anchor (⑤) into the wall, as shown above.




C: Affix the L-shaped Metal Bracket (③) to the wall.

(Caution: The space between the Dresser Restraint Strap (④) and the Metal Brackets (③) on the Dresser and the wall should be a maximum 3.5".)

Then affix one L-shaped Metal Bracket (③) to the hole in the wall using the 4cm Self Tapping Screws (②) and Screwdriver (⑧)(not provided).

Repeat this step to affix the other Metal Bracket (③) to the wall as shown above.



D: Move the Dresser against the wall. Then pull the Dresser Restraint Strap (④) through the two Metal Brackets (③), one by one, and lock the Dresser Restraint Strap (④) tight, as shown above. The Dresser Restraint Device is now installed and is ready for use.

Care & Maintenance

- ☐  ☐ Do not put hot items directly on furniture surface.
- ☐  ☐ Do not clean furniture with harsh cleansers or polish.
- ☐  ☐ Do not place furniture under direct sunlight.
- ☐  ☐ Do not place furniture near heating or cooling vents.
- ☐  ☐ Do not write on furniture without a padded barrier to protect the surface.
- ☐  ☐ Do not place furniture outside. For indoor use only.
- ☐  ☐ Not for commercial use. For residential use only.
- ☐  ☐ Stains may be removed with mild soap solution and damp cloth.
- ☐  ☐ Children should not climb or jump on the furniture.

- ☒  ☐ Dust and pick-up spills using a clean, non-colored, lint-free cloth.