


ASSEMBLY INSTRUCTIONS



Estimated Time for Assembly

45:00












Weight Limitation


LB

330 lb Chair

165 lb Table

PART LIST

A Chair Seat  (2 pcs)	B Front Leg  (2 pcs)	C Rear Leg  (2 pcs)	D Seat Cushion  (2 pcs)
E Back Cushion  (2 pcs)	F Bolt M6*35mm  (8 pcs)	G Allen Key  (1 pc)	H Table  (1 pc)
I Table Glass  (1 pc)			



Do not fully tighten bolts until assembly is complete

Tools Needed

All necessary tools are included in the package.

NOTE:

The instruction booklet contains **IMPORTANT** safety information Please read and keep for future reference.


Step 1
Chair

B Front Leg **C** Rear Leg



(1 pc)

(1 pc)




Step 2 Chair

A Chair Seat **F** Bolt M6*35mm **G** Allen Key




(1 pc)



(4 pcs)




(1 pc)



Step 3 Chair


D Seat Cushion **E** Back Cushion



(1 pc)



(1 pc)



Step 4 Table


H Table **I** Table Glass



(1 pc)



(1 pc)



Warranty

All of our products come with a 1-year warranty.

In case of damage caused by non-human factors, we will provide free return and exchange services.



Replacement



You

You don't have to worry about re-packaging / schedule pick-up.

Service

Looking forward to the completed product after assembly! As all our products are handmade, some uncontrollable factors may arise. If you encounter any quality issues with the product or experience difficulties during assembly, please do not do not panic! Kindly contact us as soon as possible. Our customer service team will provide you with the fastest solution and offer you quality and professional service.

FURNITURE CARE AND MAINTENANCE

Polyrattan Furniture

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly.
- Check the tightness of all bolts every 2 months, tighten them if necessary.



CLEANING (CUSHION)

- Leave the filling inside the cover.
- Gently spray and wash the surface to remove any dirt and grime.
- Agitate the surface with natural soap (not detergent).
- Rinse the cushion with cold water.
- Fully air dry the cushion before using or storing.

⚠ DO NOT apply heat to the fabric.

⚠ DO NOT put fabric into washing machine or tumble dryer.

CLEANING (POLYRATTAN)

- Remove all cushion from the furniture.
- Spray and wash the furniture with warm water to remove dirt and dust.
- Use mild soap solution and agitate with a soft brush if necessary.
- Rinse the furniture with clean water to remove residue or any soap solution.

⚠ DO NOT wash the product with pressure washer or solvent based, abrasive powder, chlorine bleaches or silicone cleaner to prevent damaging the product.



STORAGE

- All polyrattan furniture and cushion should always be air dried before storage.
- To protect the appearance, the furniture should be protected from all severe weather or strong direct sunlight and stored under cover.