






















Assembly manual




① X1 	⑥ X1 	A X1 	F X5 	L X4 8X50 
② X1 	⑦ X1 	B X1 	G X16 M3. 5*12 	M X4 8X50 nickle 
③ X1 	⑧ X1 	C X1 	H X2 GLASS 	N X8 8X35 
④ X1 	⑨ X1 	D X1 	J X4 4X30mm 	P X16 
⑤ X1 		E X1 	K X1 	Q X8 Adjust the foot nail 




(1)




(2)




(3)




(4)




(5)




(6)




(7)



(8)



(9)



(10)

