

Assembly Instructions

Hickory Writing Desk



Thank you for choosing our product.

We hope that this piece brings you many years of enjoyment!

For help with assembling your furniture,
or if you have missing hardware, please email us.

PARTS (included)

(A) Desk Top (1)

(B) Legs (4)



HARDWARE (included)

(a) 5/16" Washer (8)



(b) 5/16" Hex Nut (8)



TOOLS NEEDED

1/2" Wrench or Socket

STEP 1

Attach one leg to each corner of the desk top. (See photo 1.) Make sure the bolts in the legs are inserted properly through the corner brackets. Put a 5/16" washer on each bolt followed by a 5/16" hex nut. (See photo 2.)




photo 1




photo 2

STEP 2

Set the desk upright on the floor and test for stability. If it rocks or wobbles you may have to adjust 1 or 2 of the levelers on the bottom of the legs. (See photo 3.) You should be able to turn these with your fingers, if not you can use pliers.



photo 3