



STEP 3



Recommended Maximum Weight





WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.


>DO NOT allow children to climb on unit.

> Put heavier items on lower shelves.







Assembly Instruction


Turn-N-Tube 3-Tier TV Stand



HARDWARE & PARTS LIST

NO	HARDWARE LIST	QTY
1	METAL LONG POLE 	5pcs
2	METAL SHORT POLE 	5pcs
3	ROUND LEG 	5pcs
4	PLUG LEG 	1pc

NO	PARTS LIST	QTY
A	TOP PANEL	1pc
B	SHELF PANEL	1pc
C	BOTTOM PANEL	1pc




USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damp cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

ASSEMBLY INSTRUCTIONS

BEFORE YOU BEGIN, PLEASE READ ASSEMBLY INSTRUCTION CAREFULLY, FOLLOW THEM STEP BY STEP.

STEP 1



STEP 2

