



Thank you for purchasing this product. Please read this manual carefully before using it and install the grill correctly. To prevent accidents when using this product, please be sure to use it correctly and be sure to follow the precautions. Please keep this manual.

* The shape and storage position of the parts may differ from the actual ones. Please understand !

● Please read the method of construction and precautions carefully. Please build according to the order marked in the figure below. When disassembling, please disassemble in reverse order.

product list

- BBQ Grill Main Body 1pc
- Charcoal Groove 1pc
- Charcoal Net 1pc
- Grill Net 2pcs
- Anti-hot handle 1pc
- foot tube(short) 2pcs
- foot tube(short) with Adjustment module 2pcs
- foot tube(long) 4pcs

* The two metal plates of the grill body, due to the characteristics of aluminum alloy processing, will have fine scratches and small stains on the surface during the molding process. Please understand that this is technically unavoidable.

When the grill is used in high gear.

1 Turn the grill body over and insert 2 feet (short) and 2 feet (short) with the adjustment module into the grill as shown below.

● Please note the position of the foot tube with adjustment module (diagonal mounting).

Barbecue Body

■ Before use, please clean the grill net

Use anti-hot gloves

■ The product itself is a metal product. There are sharp edges. When installing, lighting, extinguishing, and touching by hand, use anti-hot gloves to avoid injury. Wear rubber gloves when cleaning.

When the grill is used in low gear.

Please connect the four long leg tubes to the body first, and then connect the two short corner tubes and the two short leg tubes with the adjustment module firmly into the four long leg tubes.

After the setup, the grill will be slightly unstable. Please rotate the adjustment module to fine-tune the height. Try to keep the grill horizontally stable. When the ground is uneven outdoors, you can use the adjustment module to adjust.

Adjustment module (screw)

Part names

Carbon slot, Frame tube, Barbecue Body, Buckle, Slide guide, Vent hole, handle, Thermal reflector, Carbon slot, Hanging plate, Slide guide slot, foot tube(short), Side view of the grill body fitted into the carbon tank.

[Figure-1]

2 After the foot pipe is connected and installed, insert the carbon slot into the grill body from either side of the grill body.

Carbon slot, Barbecue Body, [Figure-2], [Figure-3]

Insert the slide guide of the carbon slot horizontally into the slide guide groove of the grill. In order to prevent the carbon slot from slipping and causing the carbon slot to fall, a hanging buckle is provided in the sliding guide groove of the grill body. When inserting the carbon slot, the central buckle of the sliding guide groove catches the carbon slot sliding guide. Front buckle. Prevent the sinking of the carbon tank and cause accidents such as personal injury. When inserting the carbon tank, please refer to Figure 2 and Figure 3 to slightly tilt the front end of the carbon tank, over the rear hanging buckle.

■ The picture of hanging buckle & buckle part

Barbecue Body, Hanging buckle, Buckle, Slide guide, Carbon slot, Slide guide slot, handle, Carbon slot

Use the handle to slide the Carbon slot into the grill body

When the carbon tank passes through the grill body, slightly tilt the front end of the carbon tank over the hanging buckle.

[Figure-2], [Figure-3]

About the use of carbon slots

● Carbon slot can be used to pull and change carbon, and the carbon slot can slide out from the left and right sides of the grill body

● Buckle Function

Barbecue Body, Hanging buckle, Buckle, Carbon slot, Slide guide slot, Handle, Slide guide

[Figure-4], [Figure-5]

movement of the carbon slot when using

Barbecue Body, Hanging buckle, Buckle, Carbon slot, Slide guide slot, Handle, Slide guide

[Figure-5]

● When sliding the carbon slot, use the handle

● When sliding use carbon tank, be sure to keep horizontal movement

● Do not allow children to use this product. Do not allow children or pets to play around the appliance when using

● Pull out the carbon tank, because the role of the buckle can only pull out half. It is strictly prohibited to pull out more than half, otherwise the carbon tank will fall off, very dangerous

Attention !

● When moving the carbon slot during use, wear heat-resistant gloves to prevent burns, scratches, etc

● When moving the carbon tank during use, be sure to move horizontally

● When moving the carbon tank during use, do not let the carbon tank accidentally slip out of the carbon tank during the movement, do not let the carbon tank fall off the buckle when moving

Color Classification: AIR90 (Black), AIR90 (Wine red), AIR90(golden)

Grill Body: Aluminum alloy
Carbon slot: 201 stainless steel
Leg tube: aluminum alloy
Foot adjustment module and foot pad: 201 stainless steel
Grill net: 201 stainless steel
Number of users: 2-8 people
Expand Size: (about) 88*60*43/80cm
Storage size: (about) 68*37.5*13cm
product weight: (about) 4.9kg
The size of Grill Net: (about) 30*25cm

3 Place the carbon mesh on the carbon tank

Carbon net, Fine adjustment of height

Before lighting the carbon, please reconfirm the balance of the grill. If it is found to be unstable, adjust the height using the two adjustment modules that touch the foot tube.

4 Place the grill net as shown in the figure

Grill Net

● Conversely describe the use of this product and precautions for use, please be sure to read

Grill Body: Aluminum alloy
Carbon slot: 201 stainless steel
Leg tube: aluminum alloy
Foot adjustment module and foot pad: 201 stainless steel
Grill net: 201 stainless steel
Number of users: 2-8 people
Expand Size: (about) 88*60*43/80cm
Storage size: (about) 68*37.5*13cm
product weight: (about) 4.9kg
The size of Grill Net: (about) 30*25cm

Color Classification: AIR90 (Black), AIR90 (Wine red), AIR90(golden)

Use caution

● To prevent accidents, injuries, etc., be sure to observe the following. (This product has a sharp part, please pay attention to protection. When installing the grill, be sure to wear anti-hot gloves when lighting. When cleaning the grill, be sure to wear rubber gloves to avoid injury.)

About fuel (please pay attention to excessive fuel)

● using charcoal occasion

1. When using a solid oxidizer, light the solid oxidizer. After ignition, the charcoal is stacked on top of the oxidizer and stacked as compactly as possible. When using coloidal flame materials, place the carbon on a carbon grid and apply the flame retardant over the bottommost layer of carbon. Coloidal oxidizer is very dangerous. Do not add oxidizer to the combustion state.

2. After all the carbons have been confirmed to ignite, pave the carbon evenly on the roasting net. The amount of carbon should be properly placed according to the amount of ingredients.

● Be careful not to put in excess carbon. Too strong firepower can cause serious distortion and discoloration of the appliance. Poor charcoal can affect the grilling effect.

Attention !

● When using, please be sure to place the grill outside house

● There are sharp parts in the product. Remove, install, ignite, and always wear anti-hot gloves when touching by hand. Be sure to wear rubber gloves when cleaning. Be careful to avoid injury when cleaning.

● Please be sure to use a barbecue grill in a place where there is enough space to ensure the safety of the surroundings

● Carbon net, roasted net may cause deformation due to heat, please know

● The two metal plates of the grill body, due to the characteristics of aluminum alloy processing, will have fine scratches and small stains on the surface during the molding process. Please understand that this is technically unavoidable. Thanks

● After using the grill, wash it and dry it. Store this product in a well-ventilated dark place, away from hot, humid places

● After using the charcoal fuel, etc., be sure to wait until it is completely burnt and exhausted. Confirm that the appliance is cooled before handling it.

● Burning carbon, ash, etc. Please handle it properly. We all protect our good environment together

Prohibited!

● Before use, be sure to confirm whether the parts are damaged or bad welding. If found damaged Do not build use

● Do not move the grill after lighting. Do not touch the grill in use with bare hands. It is very dangerous to change the high and low grades during use. Do not adjust the high and low gears

● Do not place grills on slopes, bumpy floors, etc., in unstable places

● It is forbidden to use barbecue grills inside houses, balconies, garages, tents, and pergolas

● Do not use barbecue grills in a flammable environment

● After the ignition of carbon, there will be a burst of carbon blocks or a jump in firepower. Please do not bring the head of the face close to the grill

● It is forbidden to use gasoline, kerosene, flammable gas, liquid alcohol, etc. as lighting agent or fuel. It is very dangerous, strong wind, and when it is raining, do not use barbecue grills.

● Do not allow children to use this product. Do not allow children or pets to play around the appliance when using

● Pull out the carbon tank, because the role of the buckle can only pull out half. It is strictly prohibited to pull out more than half, otherwise the carbon tank will fall off, very dangerous

Warning!

● Removal of carbon tanks, installation and use of carbon tanks for movement, adjustment, fuel replenishment, etc. Please be sure to wear heat-resistant gloves when handling

● When using a gel-like oxidizer, add the combustion aid vertically down from the grill. Be careful not to inject gel-like oxidizer outside of carbon. Otherwise, it will increase the scope of combustion, it is dangerous, and please do not add gel-like combustion improver in the combustion state, very dangerous, please note

● Adding too much carbon or other fuel can cause distorting discoloration of the device and impede the free movement of the carbon channel. Do not do this if it is not necessary.

● Do not use after to extinguish the carbon in the burning state in the carbon tank when the charcoal fire is eliminated. The sharp temperature difference can lead to deformation of the appliance

● High temperature flame steam is very dangerous

● After the charcoal fuel remain extinguished. Be sure to wait until the appliance is completely cooled before proceeding.

● After use, pay attention to the carelessness of the goods and the collapse of the product when disassembling the grill. Please pay careful attention to the dropping of the items on the grill during use.

● Incorrect use of this product will result in damage to the product! If it is stored under incorrect conditions. Under the wrong use for a long time, under the wrong preservation conditions, this product will be damaged, deteriorated, acidified and corroded. Our company will not bear any responsibility. Please be aware of this.

● Due to the different characteristics of the product and the place of use, the difference in the environment of the place has different levels of wear and tear on the product. When the product is left for more than one year, be sure to confirm if the product is damaged before use, and confirm there is no damage before use. Since the product is a consumable product, we cannot guarantee the safety of the product if you purchase the product for more than 2 years, please understand.