

CARE AND MAINTENANCE










Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Product Dimensions: 30.51" W x 32.48" D x 33.07" H

Parts List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Front Leg - 1		1X
B	Front Leg - 2		1X
C	Back Leg - 1		1X
D	Back Leg - 2		1X
E	Seat		1X
HW1	Socket Bolt 8 x 1 x 58 mm		8X
HW2	Flat Washer 8.5 mm		8X
HW3	Split Lock Washer 9 mm		8X
HW4	Allen key		1X



Weight Capacity: 275 lbs

WARNING: DO NOT STAND ON CHAIR

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 25 minutes.

