










Product Instruction



A+B+B




A+B


A (Sofa)	 x1	 x1	 x2	 x2
B (Stool+Median)	 x1	 x1	 x1	

Instruction



STEP:1








STEP:2



STEP:4



STEP:3



The sofa cushions need 72hours to decompress and fully inflate before using them.

If you find wrinkles in the fabric after 72 hours, you can use a steam ironing treatment. The back cushions are removable and washable, while other non-removable parts can be cleaned with a detergent.