

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening
- * This item may require a pair of pliers to unscrew the screws to a suitable length during assembly when feet are too short to fit into the item.














PREPARATION

- *Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *Estimated Assembly Time: 5 minutes.


CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

Part List and Hardware List

| PIECE | DESC. | PICTURE | QUANTIT | PIECE | DESC. | PICTURE | QUANTITY |
|-------|-----------------------------------|---|---------|-------|---------------------|--|----------|
| A | Table Top |  | 1X | B | Right Middle Panel |  | 1X |
| C | Left Middle Panel |  | 1X | D | Right Side Panel |  | 1X |
| E | Left Side Panel |  | 1X | F | Back Panel |  | 1X |
| G | Bottom Panel |  | 1X | H | Cushion |  | 1X |
| I | Basket Frame |  | 3X | J | Basket Bottom |  | 3X |
| HW1 | Phillips Screws 6.14x1.27x35mm |  | 16X | HW2 | Allan Key Driver |  | 1X |
| HW3 | Allen bot 5x1x14mm |  | 12X | | | | |

Product Dimensions: 47" W x 16" D x 20.25" H




Weight Capacity: 175LBS

Warning: Do not stand on the Bench







Warning: Do not over torque bolts.

Additional Tools Required

| | |
|---|---------------------------|
|  | Screwdriver (not include) |
|---|---------------------------|

PREPARATION

- *Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *Estimated Assembly Time: 5 minutes.
- *If you are having difficulty, our friendly Customer Care team is always here to help.

| | | |
|--|--|--|
|  |  |  |
| Step 1: Put the bench top(A) upside down, attached the middle panel (B) and (C) to the bench top (A) by using 4pc longer screws(HW1). | Step 2: Attach the right panel (D) to the bench top(A) by using 2pc longer screws (HW1). Insert the back panel (F) into the groove of side panel and bench top | Step 3: Attach the left panel (E) to the bench top(A) and back panel (F) by using 2pc longer screws (HW1). |
|  |  |  |
| Step 4: Put the bottom panel(G) over the back panel(F) and middle panel(B)&(C),make sure back panel(F) insert the bottom groove of bottom panel(G). Using 8screws(HW1) to connect bottom panel(G) with middle panel(B)&(C), right and left panel(D)&(E). | Step 5: Open up the basket frame(I), attach the basket bottom(J) to basket frame(I) by using 4 Shorter Screws(HW3) and Allan Key Driver (HW2). | Step 6: Turn the bench up to right side, put on the cushion and baskets. |