




MULTIFUNCTIONAL DIGITAL HEAT PRESS MACHINE

USER GUIDE

MULTIFUNCTIONAL DIGITAL HEAT PRESS MACHINE



Customer Support

IMPORTANT: If you need help regarding product issues, after sale service, or other relevant problems, please contact us via email:



support@akeydiy.net



Please provide the following information:

Order ID

Problem Description

IMPORTANT: Be sure to review the contents of this manual before attempting to operate the equipment. This manual should be located where it can be easily referenced by all users of the machine.

CONTENTS

HEAT PRESS MACHINE PARTS INTRODUCTION	3
--	----------

PARTS LIST	4
-------------------	----------

ASSEMBLY & USE STEPS	5
---------------------------------	----------

INTELLIGENT TEMPERATURE CONTROLLER OPERATION METHOD	6
--	----------

I. PREPARATION BEFORE USING	6
-----------------------------------	---

II. SET TEMPERATURE REQUIRED.....	6
-----------------------------------	---

REPLACE BAKING TRAY MAT.....	8-9
------------------------------	-----




REPLACE BAKING CAP MAT.....	10-12
-----------------------------	-------

REPLACE BAKING COASTER.....	13-14
-----------------------------	-------


III. PRINTING METHODS	15
-----------------------------	----

IV. TROUBLE SHOOTING FOR TRANSFER QUALITY.....	15-16
--	-------

HEAT PRESS MACHINE PARTS INTRODUCTION



PARTS LIST



	Part A	Part B	Part C	Part D	Part E	Part F	Part G	Part H	Part I	Part J
5in1 Heat Press	✓	✓	✓	✓	✓	✓	✓			
8in1 Heat Press	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓



1PC


A Phillips screwdriver can be turned into a slotted screwdriver by rotating it 180 degrees




1PC

ASSEMBLY & USE STEPS


1




2




3



4



5



INTELLIGENT TEMPERATURE CONTROLLER OPERATION METHOD

I.Preparation before Using:

- 1.Check the connection between power plug and electrical socket of electrical cabinet.Be sure to operate with safe ground wire!!!
- 2.Heat press element must be securely plugged into the machine before you switch the machine on.Plug your electrical cord into the machine. Plug electrical socket into wall plug.Turn the power on by flipping the On/Off Switch on.(Nominal voltage:110V, Max.input power:900W)

II.Set temperature required

Set the temperature and time according to the table below and get the specific corresponding temperature and timing setting.(Temperature is measured in Degrees Fahrenheit.)

Press Object	Initial °F Temperature	Highest °F Temperature	Proper Heating Time (s)
Mugs	230	330	40
Tiles	230	330	40
Metal board	230	300	40
Plate	230	355	150
T-shirt	230	355	Sublimation paper:30-50s
			T-shirt Paper:10-20s

A.Initial Temperature Setting (Range:200-450°F)

Press the “MODE”button ONCE,see the “set light” turning red.Then press the “plus/minus key” to set the initial heating temperature.

B.Highest Temperature Setting (Range:200-450°F)


Press the “MODE” button for THE SECOND TIME;see the “temperature light” turning red.Then press the “plus or minus key” to set the highest heating temperature.

C.Proper Heating Time Setting (Range:0-999 sec.)

Press the “MODE” button for THE THIRD TIME;see the “time light” turning red.
Then press the “plus or minus key” to set the proper heating time.

D.Finish the Setting and Stands by to Work

Press the "MODE" button for THE FOURTH TIME; finish the setting  , The set light is on, and the temperature will continue to rise. When the set maximum temperature is reached, the countdown starts. After the countdown ends, the "BEEF" sound will be emitted, the indicator light will turn off, and the operation is complete. and the machine stands by to work.




Turn off the power and pull out the mat. It is recommended to wear heat-resistant gloves when removing clothes or remove them after 2-3 minutes. Be careful of hot heat.

Note


- The machine has a self -locking function for temperature setting.
 - If the starting temperature is set to 340°F, the machine will automatically limit the maximum temperature setting range from 340 to 430°F.
 - Conversely, if setting the maximum temperature as 250°F at first, the machine will automatically limit the starting temperature setting range from 200 to 250°F.
- Initial heating temperature always = < Highest heating temperature

Replace Baking Tray Mat


3



Choose the right size
Plate Press.




combination




separate

4



A and B




plate




Patterned plate

Replace Baking Cap Mat

1




2




Replace Baking Cap Mat


3



4




5




Install the baking pad (Part D)

Replace Baking Cap Mat

6




Use the screwdriver 4 to tighten the 2 screws just removed and put the cap on.



Shaped hat


Replace Baking Coaster

1




Install H to Part E.
(Tighten the screws on both sides. We suggest
to tighten the screws on the side ① first, and
then tighten the screws on the side ②)


Select the appropriate size
baking coaster (Part F or G).
Put the cup in Part E.



2




Adjust the tightness.



Shaped cup

Replace Baking Coaster


1




And install I or J to Part E.
(Tighten the screws on both sides.
We suggest to tighten the screws on
the side ① first, and then tighten the
screws on the side ②)

Put the cup in Part E.

2



Adjust the tightness.



Shaped cup

III. Printing methods

Adjust pressure to your requirement (Neither too tight nor too loose),
Plug in the power cord and turn the power switch ON.

The temperature starts to rise. Set the Initial temperature, Highest Temperature and press time.

Once the temperature rises to the Initial temperature, the buzzer will send out a shot “BEEF” sound.

Press the  button once. Then place the object (i.e. T shirt) on the press bed. Pull down the handle to press the object.

Wait for the time ends up with a long buzzer sound. (Note: There will be about 5s time for long buzzer to notify you it has finished, and after that will appear 5s for short buzzer to notify you whether you still go on the next work, if not the temperature will fall down to the Initial temperature.)

Work finish and take out object.

Turn off the power switch.

IV. Trouble shooting for transfer quality

Pale Color: The temperature is too low/the pressure is not correct/or not pressed long enough.

Blurring Pattern: Too much transfer time causes proliferation.

Part Blurring of Pattern: Heat was not distributed correctly through heat plate.

Allow more time between press operations. Pressure distribution can also be the cause, which can be set on the four plate surface adjusters. Please note that it has been factory set and there should be no need to adjust them.

Dull Surface of Pattern: The pressure is too large or the temperature is too high.

Scarred Pattern: Transfer time is too long.

Different Pattern Color: The pressure is not correct or the transfer paper is poor quality.

Adhesive Paper: the temperature is too high or poor printing ink.



CAUTION

- CHECK the correct voltage before using the machine.Be SURE to operate with reliable grounded protection connections.
- TURN OFF the machine,and then DISCONNECT the power-supply before replacing the heat units.DO NOT forget to wearing insulated gloves if the unit is still under high-temperature.
- AVOID prolonged burning of the heating parts.If not turning the power off, please place a hot stamping replacement (it could be a scrap and can be used repeatedly).AVOID damaging the heating units with sharp parts of the stamping object.
- AVOID touching the heating units and the compression spring without protection in case of potential damage,of body during use.
- If it's hard to pushing the grasp,please adjust the rotation lock screw in order to reduce the pressure of compression spring.Or, it will damage to the strength of the machine.
- Before lifting the machine,please lock the machine head by rotation lock screw and loosen the handle(don't screw the rotation lock screw too tight).Besides, do not put down the machine beyond the limit.When meeting the falling limit, you can feel an obvious pressure on the swiveling pressure adjustment wheel.
- Keep children away from the machine!!!
- DO NOT attempt to press products that are not intended for normal heat transfer. Baking pads should be avoided of empty burning.

Brand Story

AKEYDIY, founded in 2020, is committed to nurturing children's hands-on abilities and encouraging them to explore, discover, and experience different things through active and imaginative play.

The founder, George Akey, is a young man who is not only a father of two children but also deeply passionate about DIY. He firmly believes that every child has immense creative potential, and with the right opportunities and tools, everyone can unlock their DIY potential.

George's inspiration for his first product came from children's dreams of creating their own costumes. However, the quality of heat press machines on the market varied greatly, and the prices were discouraging. Determined to fulfill kids' dreams, George conducted extensive research on heat transfer technology, continuously improving and perfecting it. After months of effort, he finally manufactured a durable and user-friendly machine. This machine became like a key, unlocking infinite creative potential for DIY enthusiasts.

Over time, the AKEYDIY brand gradually grew and expanded. In addition to the heat press machine, they introduced various products such as bounce houses and water slides, aimed at helping families create more joyful moments.

AKEYDIY is dedicated to providing opportunities for people to bring their creative ideas to life, allowing each individual to find enjoyment and a sense of accomplishment in the DIY process.

The logo for AKEYDIY features the word "AKEY" in a bold, black, sans-serif font, followed by "DIY" in a bold, black, sans-serif font. The "DIY" is set against a yellow background that is part of a larger yellow parallelogram shape.

support@akeydiy.net



MADE IN CHINA