

MASTER-MARINER

BAROMETER INSTRUCTIONS



If you intend to use your Barometer at an altitude above 100ft above sea level it is necessary to adjust the mechanism by means of the rear brass slotted screw.

1. Check with Local Weather Bureau or TV forecast service to find the barometric pressure - 'Day's Reading' for your area. This will be given in either Inches of Mercury (Hg), Kilopascals (KPa) or Millibars (Mbs). KPa and Mbs are numerically the same.
2. Using a small screwdriver rotate the brass set screw in small increments until the black hand is registering the same Day's Reading value you have obtained in #1 above.
3. Your Barometer will now be indicating a 'Corrected to Sea Level' pressure. It is Standard International procedure to reference all pressures as if they were at sea level.
4. Now follow the TREND instructions printed at the bottom of the instrument dial face.