

## NOTICE

- \* Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.
- \* If you are having difficulty, our friendly Customer Care team is always here to help.










## PREPARATION

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 20 minutes.
- \* Tools Required for Assembly (included): Allen Key

## CARE AND MAINTENANCE

- \* Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
- \* The use of steam or water-based cleaners may cause excessive shrinking or staining.

Parts List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Front leg-1		1X
C	Front leg-2		1X
D	Back leg-1		1X
E	Back leg-2		1X
HW1	Hex bolt 60 x 5 x 1 mm		8X
HW2	Split lock washer 6 mm		8X
HW3	Flat washer 6 mm		8X
HW4	Allen key		1X

Product Dimensions:19.68" W x 23.62"D x31.89" H



Weight Capacity: 275 lbs







Warning: Do not stand on chair

Warning: Do not over torque bolts



## PREPARATION

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time: 20 minutes.
- \* Tools Required for Assembly (included): Allen Key
- \* If you are having difficulty, our friendly customer care team is always here to help.

<p><b>1</b></p> 	<p><b>2</b></p> 	<p><b>3</b></p> 
<p>STEP1: OPEN THE ZIPPER ON THE UNDERSIDE OF THE SEAT (A) AND TAKE OUT LEGS AND HARDWARE</p>	<p>STEP2: PUT THE WASHERS (HW2, HW3) ON THE BOLT (HW1) IN THE ORDER SHOWN IN THE PICTURE</p>	<p>STEP3: INSERT THE FRONT LEGS (B, C) AND SCREW IN THE BOLTS BUT DONT TIGHTEN COMPLETELY</p>
<p><b>4</b></p> 	<p><b>5</b></p> 	<p><b>6</b></p> 
<p>STEP4: INSERT THE BACK LEGS (D, E) AND SCREW IN THE BOLTS BUT DONT TIGHTEN COMPLETELY</p>	<p>STEP5: PUT THE CHAIR UPRIGHT AND MAKE SURE ALL LEGS ARE LEVEL, THEN FIRMLY TIGHTEN BOLTS WITH ALLEN KEY (HW4) WHILE THE CHAIR IS UPRIGHT AS PICTURED ABOVE</p>	<p>STEP6: CLOSE THE ZIPPER ON THE UNDERSIDE OF THE SEAT, THIS ITEM MAY REQUIRE PERIODIC TIGHTENING</p>