

END TABLE

ASSEMBLY INSTRUCTION



ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly




Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately .
2. This product is for home use only and not intended for commercial establishment.


PARTS IDENTIFICATION:

B2: A GLASS



1 PC

B1: B WOOD




1 PC

C LEG



1 PC




ASSEMBLY TIME PER UNIT: 5 MINUTES

Z HARDWARE PACKAGE:

NO	DESCRIPTION	FIGURE	Q'TY
1	CHROMED SCREW		4 PCS
2	SCREW		4 PCS
3	CHROMED FLAT WASHER		4 PCS
4	FLAT WASHER		4 PCS
5	ALLEN WRENCH		1 PC
6	ADJUSTER		4 PC

STEP 1



STEP 2

