

INSTRUCTIONS MANUAL



PATIO WICKER SWIVEL CHAIR AND SIDE TABLE

Loosely assemble before tightening.

IF YOU PURCHASED THE SWIVEL CHAIR AND SIDE TABLE ONLINE
AND HAVE ANY QUESTIONS OR CONCERNS
PLEASE CONTACT US VIA EMAIL, TEXT, OR PHONE

Date of Manufacture: 25W15

Warning:

1. Very important!


After receiving the product, please check if all parts are intact.

Do not open the vacuum-sealed packaging of the cushion immediately.

Only proceed with opening the packaging if you are satisfied with the product.

2. When unpacking the box, please use tools carefully to avoid scratching the cushion.

Note: If you are not satisfied with the product after opening the packaging of the cushion, it may affect the after-sales process.



Warning and Cautions:

Thank you for choosing our furniture. Please read and understand this entire manual before attempting to assemble or install the product.

GENERAL BEST PRACTICES FOR ASSEMBLY

1. Familiarize yourself with the product and check all parts against the packing list. If any Parts are missing or damaged, do not install. Contact us immediately.
2. Some parts may contain sharp edges. Wear protective gloves, if necessary, during assembly.
3. Check all nuts and bolts periodically for tightness and, when required, tighten them again.
4. Pay attention to the parts orientation.
5. Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.

IMPORTANT

- Make sure to place the washer on the bolt before inserting it into the bolt hole.
- To ensure the best fit, assemble loosely before tightening.
- Tighten all bolts after all parts are assembled.

WARNINGS

 **Keep children and pets away from the working area during assembly and adjustments.**

1. Keep the assembly area at least 6 feet from any obstruction, such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
2. When assembling and using this product, always follow basic safety precautions to reduce the risk of personal injury and product damage. Please read all instructions before assembly and use.
3. Check all bolts for tightness before use. **IMPORTANT** - check and tighten bolts often to keep them secure!
4. The chair and table are not to be used for standing purposes and will not function as a stool or step-ladder. Use on even surfaces only.
5. The chair supports a weight of 300lb (136.4 kg), and the table supports a weight of 70lb (31 kg). Improper use of the products or failure to use it as directed may result in injury. Not intended for commercial use.

WARRANTY




















•WHAT IS COVERED?

- The limited warranty is extended to the original purchaser and covers material and manufacturing defect, provided the item is properly maintained and used for personal residential purposes only.
- Warranty: 180 DAYS.
- Lost Accessories or Parts Policy: Costs for lost accessories or parts will be charged after 90 days from the date of purchase.


MAINTENANCE

- STAIN RESISTANT CUSHIONS CARE:** Keep cushions in storage on rainy days.
- SPILLS:** Immediately wipe up spills using a white damp cloth. Repeat if necessary until the stain is gone. Allow cushions to air dry.
- **FABRIC CARE:** Hand wash with cold water, non-chlorine bleach when needed, and lay flat to dry. Cool iron if necessary. Do not dry clean.
- **RESIN WICKER PRODUCT CARE:**
 1. General Cleaning: Before use, clean the product with a soft, dry towel. When not in use, wipe off any dirt or loose debris. For regular cleaning, use a mild soap and water solution, rinse thoroughly, and dry completely.
 2. Weather Protection: To prolong the life of your resin wicker, avoid prolonged exposure to intense sunlight or heavy rain. Whenever possible, use a protective cover when the furniture is not in use, especially during extreme weather conditions.
 3. Avoid Harsh Cleaners: Do not use strong detergents or abrasive cleaners, as these may damage the finish.
- Regular Maintenance:** Over time, nuts and bolts may loosen. Occasionally check and re-tighten them on all products as needed.


Assembly Instructions for 1PC Swivel Chair

A	B	CL	CR
			
1PC Chair Back	1PC Seat Panel Frame	1PC Left Armrest	1PC Right Armrest
DL	DR	EL	ER
			
1PC Left Armrest Support (with one threaded hole)	1PC Right Armrest Support (with one threaded hole)	1PC Left Armrest Support (with two threaded holes)	1PC Right Armrest Support (with two threaded holes)
F	G	H	I
			
1PC U-shaped Fitting	1PC Chair Base	8PCS Bolt M6*20mm	4PCS Bolt M6*30mm
J	K	L	M
			
8PCS Bolt M6*40mm	6PCS Bolt M6*45mm	26PCS Washer Ø16*Ø6.5*1mm	4PCS Nut M6
N	O	P	
			
8PCS Spring Washer M6	1PC Back Cushion	1PC Seat Cushion	


Tools:





PRODUCT FRAME MAP



1. Secure chair armrests (CL&CR) to armrest supports (DL,DR,EL&ER) with 8 bolts (H) and 8 washers (L) by using allen wrench. Keep the bolts loose.




H		M6*20mm	8
L		Ø16*Ø6.5*1mm	8








Note: After assembled, keep all the threaded holes inwards.

2. Secure U-shaped fitting (F) to chair base (G) with 4 bolts (K), 8 washers (L), 4 spring washers (N) and 4 nuts (M) by using allen wrench and spanner.



Keep the bolts loose.





K		M6*45mm	4
L		Ø16*Ø6.5*1mm	8
M		M6	4
N		M6	4




3. Secure chair back (A) to seat panel frame (B) with 2 bolts (K) and 2 washers (L) by using allen wrench. Keep the bolts loose.

K		M6*45mm	2
L		Ø16*Ø6.5*1mm	2






4. Secure assembled armrests (CL&CR) to assembled chair back (A) with 2 bolts (J) and 2 washers (L) by using allen wrench. **Keep the bolts loose.**

J		M6*40mm	2
L		Ø16*Ø6.5*1mm	2






5. Secure assembled armrest supports (DL,DR,EL&ER) to assembled seat panel frame (B) with 6 bolts (J) and 6 washers (L) by using allen wrench. **Keep the bolts loose.**

J		M6*40mm	6
L		Ø16*Ø6.5*1mm	6



6. Secure assembled U-shaped fitting (F) to assembled seat panel frame (B) with 4 bolts (I) and 4 spring washers (N) by using allen wrench. **Fully tighten all bolts now.**

I		M6*30mm	4
N		M6	4



7. Put the seat and back cushion (P&O) onto the chair, and it is ready for use now.



SPECIAL WARNING










**THIS CHAIR IS NOT A TOY.
DON'T OVER-SWING THE CHAIR.
OVER-SWING THE CHAIR MAYBE
MAKE THE CHAIR TIP OVER AND
RESULT IN INJURY.**





**DO NOT STAND ON THE
CHAIR. ANY IMPROPER USE
OF THIS PRODUCT MAY
RESULT IN INJURY.**


Assembly Instructions for 1PC Side Table

A	B	C	H
			
1PC Table Top	14PCS Table Leg	1PC Table Tray	8PCS Bolt



R	L	Tool: 
 M6*30mm	 Ø16*Ø6.5*1mm	
4PCS Bolt	12PCS Washer	Ratchet Wrench


1. Secure table legs (B) to table top (A) by using 8 bolts (H) and 8 washers (L) by using supplied tool. Keep the bolts loose.

H		M6*20mm	8
L		Ø16*Ø6.5*1mm	8



2. Secure assembled table legs (B) to table tray (C) by using 4 bolts (R) and 4 washers (L) by using supplied tool. **Then fully tighten all bolts now.**

R		M6*30mm	4
L		Ø16*Ø6.5*1mm	4



3. Roll over the table and it is ready to use now.

