

### To Adjust Height of Extension Arm

Loosen Wing Nut and rotate Extension Arm with Shower Head UP or DOWN to desired position (Fig. 3). Hand-tighten Wing Nut to lock Extension Arm height and to seal connection from leakage.

### Hydro-Powered, No Batteries or Electricity!

LED lights are powered by running water, so no batteries are needed. LED lights have long life of 100,000 hours (over 10 years of heavy daily use).

### 3-Color Changing Water Temperature Sensor

Color of LED lights changes automatically according to water temperature:



BLUE - Cool under 95 F (35 C), GREEN - Warm 95-108 F (35-42 C), RED - Hot 109-122 F (43-50 C), FLASHING RED - Warning Very Hot over 122 F (50 C).

### If Leakage Occurs at Shower Arm Connection

Such leak is caused by Thick Washer not seated correctly or not pressing evenly against Shower Arm edge. To seal properly, Washer must stay FLAT and STRAIGHT inside Nut (Fig.D).

### You can eliminate this leak by simply re-attaching Extension Arm


1. Completely unscrew Extension Arm from Shower Arm, then hand-tighten it back on. This simple step should re-orient and straighten out Thick Washer eliminating leakage.
2. If, after repeating above step twice, leakage still remains, other options include
  - a) flipping Thick Washer up-side-down and/or
  - b) wrapping some Plumber's Tape (provided) around Shower Arm threads.



### Low Water Pressure? You can remove Water Flow Regulator

As mandated by U.S. federal law, this shower head is equipped with water flow regulator that limits maximum water flow to 2.5 gallons (9.5 liters) per minute at 80 psi water pressure. In areas with extremely low water pressure causing the shower water flow to be unsatisfactory, the flow regulator may be removed to improve the water flow in the shower head.

To remove Water Flow Regulator, using screwdriver or other pointed tool, pull up and remove Thick Washer with groove from Angle Valve of Extension Arm (Fig. E), then lift and remove Water Regulator. Insert Thick Replacement Washer without groove (included) in place of removed Washer.



**E**

[ipshowers.com](http://ipshowers.com)

**Cleaning Instructions** To maintain proper working condition, cleaning is required when mineral deposits appear on jet tips. Clean nozzles by wiping them in 50% white vinegar/50% water solution. Do not clean or rinse with harsh chemicals, heavy-duty cleaners or abrasives that may damage finish and void warranty.

**For Questions on Installation or Part Replacement Call Toll Free**

**1-888-869-4010**

Mon. - Fri. 9:00 AM - 4:00 PM Eastern Standard Time

### ONE YEAR LIMITED WARRANTY

Interlink will repair or replace any of this product's parts that exhibit defects in workmanship or materials for above stated period from date of purchase. If malfunction occurs, send only defective part(s) with proof of purchase to Customer Service Department at the address listed below. Your warranty does not cover malfunction or damage due to accident, misuse, use of harsh chemicals or failure to follow any written instructions accompanying this product. This warranty gives you specific legal rights. You may also have other rights that vary where you reside.

Interlink Products International, Inc.  
1315 E. Elizabeth Ave., Linden, NJ 07036

Patent Pending  
Made in China