


USE AND CARE MANUAL

FLOOR LAMP



Hardware (Parts are not to scale)

H1

Socket ring (Pre-assembled to the socket of the socket assembly (A))

3 pcs



THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

IMPORTANT SAFETY INFORMATION

- This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids.
 - Never cover the lamp with any object including cloth or paper as this is a fire hazard.
 - Do not handle the bulb immediately after the light is turned off as it will be hot.
 - This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
-

PREPARATION


- Before beginning assembly, installation or operation of product, make sure all parts are present. Compare parts with package contents list and diagram on previous page. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.
-

ASSEMBLY

1 Assembling the tubes onto the base

- Pull the excess power cord through the tube (G).
- Tighten the lower tube (G) onto the base (H).
- Tighten the middle tube (F) onto the lower tube (G).
- Tighten the upper tube (E) onto the middle tube (F).

NOTE: Do not twist the power cord.




ASSEMBLY (continued)

2 Assembling the socket assembly to the upper tube


- Pull the excess power cord through the tube (G).
- Tighten the switch tube (D) onto the upper tube (E).
- Tighten the tube (C) onto the switch tube (D).
- Properly fold the wire as per the method as shown in the below diagram, and insert the folded wire into tube of the tube (C).
- Tighten the socket assembly (A) onto the tube (C).

NOTE: Do not twist the power cord.



3 Installing the shades and the bulbs

- Unscrew the socket ring (H1) from the sockets of the socket assembly (A). Place the shades (B) over the sockets and secure with the socket rings (H1).




ASSEMBLY (continued)

4 Installing the bulbs

- Install the light bulbs (not included) into the sockets. Use three **MAX 40W medium base (E26) type "A"** bulbs (recommended).
- Plug into the wall outlet, turn on the switch and enjoy.

NOTE: You can also use three **MAX 9W medium base (E26) self-ballasted LED** bulbs. Do not exceed the recommended wattage.



CLEANING

- Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
- To clean the fixture, pull the plug from the wall outlet. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.

TROUBLESHOOTING

- The light does not come on at all:
 - a) Ensure whether the bulb is burned out.
 - b) Ensure the power supply is turned on.
 - c) Ensure the cord is plugged into an outlet.
 - d) Ensure the circuit breaker is set in the "ON" position.
- Fuse blows or circuit trips when light is turned on.
 - a) Check for crossed wires, ensure wiring is correct.

