



ASSEMBLY INSTRUCTION





















After unpacking, place the sofa in a dry, well-ventilated area. It will fully regain its shape and comfort within approximately 72 hours.



Slight fabric wrinkles are normal due to prolonged vacuum compression during shipping. To remove them:

- Gently shake and fluff the sofa.
- Use an iron or steamer to remove wrinkles.

A X1**B X1****C X1****D X2****E X1****G X12****H X12****01****A X1****D X1**

B X1**E X1****C X1****D X1**






GX12

HX12

06



H



G

