


# Care & Maintenance

**Caution: You must read this before you proceed**

- ⊘  ● Not for commercial use. For residential use only.
- ⊘  ● Prolonged exposure to rain may cause rusting which can stain floors.
- ⊘  ● Do not put hot items directly on furniture surface.
- ⊘  ● Do not clean furniture with harsh cleansers or polish.
- ✓  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
- ⊘  ● Children should not climb or jump on the furniture.
- ⊘  ● Do not write on furniture without a padded barrier to protect the surface.
- ✓  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- ⊘  ● Do not place the product in stone areas or areas that absorb too much sunlight.
- ⊘  ● Stains may be removed with mild soap solution and damp cloth.
- ✓  ● Keep away from sources of ignition.
- ✓  ● High-pressure water guns must not be used for cleaning. Dust and pick-up spills using a clean, non-colored, lint-free cloth.


| No | Hardware       | Fig                                                                               | Q.ty |
|----|----------------|-----------------------------------------------------------------------------------|------|
| ①  | Bolt M6x80mm   |  | 9    |
| ②  | Screw M6x55mm  |  | 8    |
| ③  | Horizontal nut |  | 8    |
| ④  | Allen Key      |  | 1    |




③ X 4

Support pole

④ X 2




Seat cushion



① X 4

Stool side cluster




X2

② X 2


Seat base

STEP 1





SKU: KS-ZC88ST/KS-ZC140ST

# ASSEMBLY INSTRUCTION




## STEP 2

**X2**




### STEP 3

X2



## STEP 4

X2



X2



## FINISH