















PARTS LIST





HARDWEAR LIST



						 4x35mm		 3x12mm	
A	58pcs	B	58pcs	C	40pcs	D	38pcs	E	56pcs
		 3.5x14mm							
F	16pcs	G	104pcs	H	8pcs	I	4pcs	J	4pcs
				 4x12mm		 			
K	2pcs	L	2pcs	M	2pcs	N	32pcs	O	1pc
				 350mm		 350mm		 350mm	
P	1pc			CL	2pcs	CR	2pcs	DL	2pcs
 350mm									
DR	2pcs								

INSTALLATIONS

STEP 1





STEP 2





INSTALLATIONS

STEP 3





STEP 4





INSTALLATIONS

STEP 5




STEP 6




INSTALLATIONS

STEP 7





STEP 8





INSTALLATIONS

STEP 9





INSTALLATIONS

STEP 10





INSTALLATIONS

STEP 11





INSTALLATIONS

STEP 12





INSTALLATIONS

STEP 13




INSTALLATIONS

STEP 14





INSTALLATIONS

STEP 15





STEP 16





INSTALLATIONS

STEP 17





STEP 18





INSTALLATIONS

STEP 19





STEP 20





INSTALLATIONS

STEP 21





STEP 22





INSTALLATIONS

STEP 23




STEP 24




INSTALLATIONS

STEP 25





STEP 26





INSTALLATIONS

STEP 27





INSTALLATIONS

STEP 28






INSTALLATIONS

STEP 29






INSTALLATIONS

STEP 30





INSTALLATIONS


STEP 31



INSTALLATIONS

STEP 32






Hinge Adjustment Guide

Three-way adjustable hinge for perfectly aligned doors


Sideways/Gap Adjustment

Turning the screw "2" on the hinges of each door allows you to adjust the door to the left or right by a few millimeters.




Forward/Backward Alignment

Loosen screw "1" to adjust the door forward or backward. After adjustment, Tighten screw "1".





Vertical Height Adjustment

Loosen screw "3" to adjust the door up or down. After adjustment, hold the door panel and tighten screw "3".




INSTALLATIONS

STEP 33





STEP 34





INSTALLATIONS

STEP 35







STEP 36






INSTALLATIONS

STEP 37








INSTALLATIONS

STEP 38



INSTALLATIONS

STEP 39



Thank you very much for purchasing from us.

We have always been trying to provide the best service and reliable products for every customer.

However, accident may happen sometimes, please contact us to resolve any issue before leaving a negative feedback.

Many thanks and welcome to our shop again!

Contact number: 323-393-8260

E-mail: chili@nxubay.com

www.amazon.com/uev