


ASSEMBLY INSTRUCTIONS

24INCH BATH VANITY (COMBO)






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
* Please assemble on a clean soft surface to avoid damage.



Tools Required



(Not Included)



(Not Included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Before Installation








Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions















		Insert Cam Bolt into hole as shown in diagram A.	
		Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.	
		Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - CABINET













Identifying the Hardware - identify the hardware using the illustrations below.








Part List

1		2	
3		4	
5		6	
7		8	
9		10	
11		12	
13		14	



Part List

15		16	
Door Mid Panel - 2pcs		Round Bar - 2pcs	
17		18	
Top Drawer Face - 1pc		Top Drawer Back Panel - 1pc	
19		20	
Top Drawer Side Panel (L) - 1pc		Top Drawer Side Panel (R) - 1pc	
21		22	
Bottom Drawer Panel - 2pcs		Bottom Drawer Face - 1pc	
23		24	
Bottom Drawer Back Panel - 1pc		Bottom Drawer Side Panel (L) - 1pc	
25		26	
Bottom Drawer Side Panel (R) - 1pc		Sink - 1pc	

Hardware List


A  ø6x35mm	B  ø14.5x12mm	C  ø8x30mm
Three in one bolts (29pcs)	Three in one lock (29pcs)	Wood dowel (34pcs)
D  ø8xø4x32mm	E  ø8xø4x25mm	F  ø8xø4x19mm
Round head screw (16pcs)	Round head screw (2pcs)	Round head screw (2pcs)
G  Handle (5pcs)	H  ø5/32"x32mm	I  ø5/32"x19mm
	Handle screw (3pcs)	Handle screw (2pcs)
J  Damping hinge (2pcs)	K  ø7xø3.5x12mm	L  ø6x30mm
	Flat head screw (12pcs)	Wood dowel (12pcs)
M  Hinge (1pc)	N  Rotary Hinge (2pcs)	O  ø6xø3x12mm
		Round head screw (8pcs)
P  Anti fall hardware (2sets)		

STEP: 1





STEP: 2

G	H	F	N	O
1PC	1PC	2PCS	2PCS	4PCS




STEP: 3

B	C
	
4PCS	4PCS






STEP: 4

B	E
	
1PC	2PCS





STEP: 5


B	C
	
8PCS	9PCS




STEP: 6




B	C
	
8PCS	9PCS





STEP: 7

M	O
	
1PC	4PCS




STEP: 8

A

8PCS




STEP: 9

B	C
	
4PCS	8PCS




STEP: 10

B	C
	
4PCS	4PCS








STEP: 11

J	K
	
2PCS	4PCS








STEP: 12

K	G	I
		
8PCS	1PC	1PC












STEP: 13

D	L	G	H
			
8PCS	4PCS	1PC	1PC




STEP: 14



D	L	G	H	I
			 ø5/32"x32mm	 ø5/32"x19mm
8PCS	8PCS	2PCS	1PC	1PC



STEP: 15




STEP: 16




STEP: 17

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.

STEP: 18



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

