
IMPORTANT NOTICE: HARDWARE PACKAGE IS ATTACHED ON THE BOTTOM OF SEAT CUSHION.

(1)x1	(2)x1	(3)x1 (L)x1 (R)
Back Cushion	Seat Cushion	Left- Arm Right- Arm
(4)x 5	(5)x1	(6)x1
Caster	Gas Lift W/ Cover	Base
(7)x1	(A)4 (A) MS	8*22 Mechanism Screw
Mechanism	(B)x3	8*18 L-bar Screw 8*55 Arm Screw 7m Cap len Key



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.



