


SKU:N707P221444



1. Thank you for choosing *our products*.

2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expectations or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solution or answer any questions you may have.

Recommendations Before Beginning Assembly



- Read instructions, cover to cover



- Have 2-4 adults on hand for assembly depending on product size



- Do not assemble directly on flooring or carpet



- Assemble on a clean non-marring surface (example: packing foam)



- Save all packaging until finished

3. Assembly Notice:

- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the

hardware spill in the box.

- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- **IMPORTANT:** When setting up your product, **DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING.** Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

Care & Maintenance



Do not put hot items directly on furniture surface



Do not clean furniture with harsh cleansers or polish



Do not place furniture under direct sunlight



Do not place furniture near heating or cooling vents



Do not write on furniture without a padded barrier to protect the surface



Do not place furniture outside. For indoor use only



Not for commercial use. For residential use only



Stains may be removed with mild soap solution and damp cloth




Children should not climb or jump on the furniture





Dust and pick-up spills using a clean, non-colored, lint-free cloth











Caution

- This product contains small components. Please ensure that they are kept away from small children.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.




SKU:N707P221444




①  x1	②  x1		
③  x1	④  x1	⑤  x1	⑥  x1
⑦  x1	⑧  x3	⑨  x1	⑩  x1
⑪  x1	⑫  x1	⑬  x1	⑭  x1

15




x1

16




x1

17




x1

18




x1

19




x2

20




x2

21



x4

22










x4


23




x4


				
Ø6x35mm	Ø15x9 mm	Ø6x30mm	Ø5x50mm	
AX18	BX18	CX12	DX10	EX1
	 Ø3x14mm			
FX2	GX54	HX8	KX2	SX4
		 Ø4x25mm		
Ø4x14mm	NX3	OX6	PX8	QX4
				
Ø6x15mm	LX2	TX2	UX4	VX3
				
Ø3x30mm				
XX16				

STEP 1




	 Ø3x14mm	
EX1	GX12	UX4


STEP 2



STEP 3






STEP4





	
Ø6x30mm	Ø5x50mm
CX6	DX6

STEP 5




		
Ø6x15mm		
RX16	LX2	TX2



OR
STEP 5-1




STEP 6





STEP 7





			
Ø6x35mm		Ø3x14mm	
AX6	FX2	GX22	VX3

STEP 8





	
	Ø15x9mm
CX6	B X6

STEP 9




STEP 10

X2




STEP 11





STEP 12

This product is equipped with S and K two similar hydraulic hinges, please pay attention to distinguish when installing.



STEP 13





NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.


Ø4X14mm
MX16



STEP 14

This product is equipped with S and K two similar hydraulic hinges, please pay attention to distinguish when installing.




			
Ø4x14mm			Ø4x25mm
MX4	KX2	NX1	OX2

STEP 15





NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.



Ø4X14mm


M X 8

STEP 16




HX8

STEP 17



	
Ø3X14mm	
G X 8	P X 8

STEP 18




Assembly Steps(EN) / Montageschritte(DE)

HOW TO ADJUST THE HINGES TO
ALIGN THE DOORS IF NEEDED.


STEP 1

Open the door.




STEP 2

Adjust the door panel upward or downward



STEP 3

Adjust the flush between door panel and side panel



STEP 4

Adjust the Gap between door panel and side panel

