

User Manual

Floor Lamp

Introduction

Thank you for purchasing Floor Lamp. Please read the following instructions carefully before use.

Product Features

- 1. Classic fishing style, embellish the space atmosphere of the room.
- 2. The lampshade is composed of two parts. The paper rope lampshade is wrapped with a linen lampshade, which is quite design-oriented and combines modernism with country style.
- 3. Usage

On/Off: Step on the foot switch.

CCT: CCT can be changed by depressing the foot switch twice.

Parameter

Lamp	
Model	
Power	MAX 60W
Material	Iron+Fabric+Rattan
Socket Type	E26
Switch	Foot switch
Bulb	
Voltage	100-120V
Power	12W
Brightness	1200LM
ССТ	Soft warm, Warm white, Cool white

Cautions


1.Please make sure that the voltage is 100-120V, which is standard for US. This product can only be used between 100-120V.


2.Unplug before cleaning.

Warranty and Our mission

Light the world, Warm your heart, which is the goal that we have been pursuing. We'd like to provide the best lamps and service to you. We provide a 12-month warranty for you. If you have any questions or suggestions, please contact us

Package List





Assembling

①-③ Use simple wrench to remove the two screws on the top of the connecting the curved tube, and connect the curved tube to the lamp holder tube; Put 2 screws in the joint, tighten with simple wrench;

(14)

12

13

- 4-8 Connect the straight tube to another straight tube;
- Tighten the screws with a wrench to connect the base and the straight tube.
- $\mathbin{\scriptsize{\textcircled{\scriptsize 1}}}{}$ Put the velcro at both ends of the cloth lampshade together.
- ②-③ Clip the bracket to the cloth lampshade.
- (4)-(5) Install the two lampshades to the lamp holder, lock the lampshade on the lamp holder with the lamp nut;
- 16 Install the bulb to finish the assembling

01 02