


TV STAND

Assembly Instructions - Please keep for future reference



Dimensions

Width-102.91inch

Depth-14.96inch

Height-76.77inch



Be careful! At least two people are required



WARNING



This product is NOT a Clothing Storage Unit (CSU).
DO NOT use it for clothing storage.
Improper use may cause furniture tipover.

Important – Please read these instructions fully before starting assembly




Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING
In order to help prevent overturning –
please follow these instructions










To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Cam Bolt 111 pcs	B  Cam Lock 111 pcs	C  Sticker 36pcs	D  8x40 Dowel 63 pcs
E  5*40mm Screw 16pcs	F  #3.5x12mm Screw 64pcs	G  #3.5x40mm Screw 8pcs	H  #3.5x15mm Screw 72pcs
I  Nail leg 14pcs	J  Metal shelf support 32pcs	K  Joint nut 14pcs	L  Screw 14pcs
M  Hinges 12pcs	N  300mm Runner 2set	O  4*60 Screw 3 pcs 6*60 Wall plug 3 pcs	P  M4*18 Screw 10pcs
Q  Handle 6pcs	R  Handle 2pcs	S  Anti-tip hardware 2set	T  Back panel clip 40pcs
			

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.


The joint is now secure.



Components - Parts


BOX:A

01




Top Panel (L&R)
466*380*15 2PCS

12




Top Panel (Center)
1696*380*30 1PC

22




Leg Panel (Center)
1695*80*15 1PC

24




Box Side Panel (L1)
1000*190*15 1PC

25




Box Side Panel (R1)
1000*190*15 1PC

27




Box Side Panel (L2)
1000*190*15 1PC

28




Box Side Panel (R2)
1000*190*15 1PC

29




Box Side Rail(L&R)
1000*50*15 2PCS

30




Box Back Panel (L&R)
1008*208*3 4PCS

32




Box Top Panel
1696*222*30 1PC

33




Box Bottom Panel (Center)
1696*190*15 1PC

38




Drawer Front
410*194*15 1PC

39



Drawer Back
351.8*130*15 1PC



















41



Drawer Side (R)
300*130*15 2PCS

Components - Parts


BOX:B

03  Side Panel (L1) 900*350*30 1PC	04  Side Panel (R1) 900*350*15 1PC	05  Side Panel (L2) 900*350*15 1PC
06  Side Panel (R2) 900*350*30 1PC	07  Back Panel (L&R) 813*208*3 4PCS	10  Leg Panel (L) 451*80*15 1PC
11  Leg Panel (R) 451*80*15 1PC	13  Bottom Panel (Center) 1665*350*15 1PC	14  Side Panel (L3) 718*350*15 1PC
15  Side Panel (R3) 718*350*15 1PC	16  Center Panel 638*350*30 1PC	17  Back Panel (Center) 324*840.5*3 2PCS
29  Box Side Rail(L&R) 1000*50*15 2PCS	34  Box Side Panel 208*190*15 1PC	37  Box Back Panel 1665*208*15 1PC
38  Drawer Front 410*194*15 1PC	45  Back Panel (Center) 324*825.5*3 2PCS	

Components - Parts


BOX:C

02




Bottom Panel (L&R)
406*350*15 2PCS

08




Front Bone (L&R)
406*60*15 2PCS

09




Shelf Panel (L&R)
404*324*15 2PCS

18




Front Bone (Center)
817.5*60*15 2PCS

19




Shelf Panel (Center L)
830.5*324*15 1PC

20




Shelf Panel (Center R)
815.5*324*15 1PC

21




Leg Center
350*65*15 1PC

23




Box Top Panel (L)
222*453*30 1PC

26




Box Top Panel (R)
222*453*30 1PC

31




Box Shelf Panel (L&R)
405*171*15 4 PCS

35




Box Side Panel
208*190*15 1PC

36




Box Center Panel
208*173*15 2PCS

39




Drawer Back
351.8*130*15 1PC

40




Drawer Side (L)
300*130*15 2PCS

42




Drawer Bottom
361.8*295*3 2PCS

43




Door Panel
586*410*15 3PCS

44




Door Panel
586*410*15 3PCS









Hardware box

Assembly Instructions




2 Height Options Of The Top Bridge: The top bridge can be installed at the same height as or higher than the height of the cabinets on both sides.






x2


STEP 1



STEP 2



(A)




Cam Bolt 24pcs

(D)




8x40 Dowel 10pcs

STEP 3



(A)




Cam Bolt 7pcs

(D)




8x40 Dowel 23pcs


STEP 4



STEP 5



STEP 6




(F)



#3.5x12mm Screw 6pcs



N1



CR

300mm Runner 2pcs

STEP 7




(F)




#3.5x12mm Screw 6pcs

N1



300mm Runner 2pcs

STEP 8



(B)




Cam Lock 2 pcs

(E)



5*40mm Screw 2pcs

STEP 9



90°


Please stand the cabinet upright
before proceeding to the next step of installation.

(B)



Cam Lock 8 pcs

STEP 10




(B)



Cam Lock 7 pcs


STEP 11




STEP 12



Please stand the cabinet upright before proceeding to the next step of installation.



Be careful! At least two people are required




(B)



Cam Lock 14 pcs

STEP 13




J






Metal shelf support 8ps

STEP 14



STEP 15






Please stand the cabinet upright
before proceeding to the next step of installation.

(B)



Cam Lock 6pcs

STEP 16




(B)



Cam Lock 2pcs

STEP 17




Nail leg 4pcs




Please stand the cabinet upright
before proceeding to the next step of installation.

STEP 18



(B)




Cam Lock 4pcs

(J)




Metal shelf support 4pcs



Be careful! At least two people are required

STEP 19




(B)





Cam Lock 6pcs

STEP 20



90




(B)



Cam Lock 2pcs

STEP 21




Please stand the cabinet upright
before proceeding to the next step of installation.



Nail leg 4pcs

STEP 22



B



Cam Lock 4pcs

J




Metal shelf support 4ps



Be careful! At least two people are required

STEP 23

X2




(G)



#3.5x40mm Screw 8pcs

(B)



Cam Lock 8pcs

(P)



M4*18 Screw 4pcs


(R)



Handle 2pcs

STEP 24

X2




(F)




#3.5x12mm Screw 12pcs

N2




300mm Runner 4pcs

STEP 25



STEP 26



(H)




#3.5x15mm Screw 24pcs

(M)



Hinges 12pcs

STEP 27



(P)





M4*18 Screw 6pcs

(Q)





Handle 6pcs



STEP 28





STEP 29




STEP 30




STEP 31




STEP 32





STEP 33



STEP 34



Be careful! At least two people are required




(B)



Cam Lock 8pcs

STEP 35




J




Metal shelf support 16pcs

STEP 36



Be careful! At least two people are required



(K)




Joint nut 6pcs

(L)



Screw 6pcs

STEP 37




(H)





#3.5x15mm Screw 48pcs

STEP 38



When the hinges are installed, you can refer to the pictures to adjust the screws of the doors till it's perfect.





1. Adjust the screws shown in Figure 1 to adjust the door up and down.



2. Adjust the screws shown in Figure 2 to adjust the door left and right to the right position.




3. Adjust the screws shown in Figure 3 and pull the door back and forth so that it can be opened smoothly.




4. After the adjustment is complete, secure the remaining two screws to secure the door in place.

STEP 39



Cam Lock 12pcs

STEP 40






Ⓔ




5*40mm Screw 6pcs

STEP 41



(B)






Cam Lock 4pcs

(E)




5*40mm Screw 8pcs

STEP 42





(T)  Back panel clip 40 pcs	(F)  #3.5x12mm Screw 40pcs
S2  Screw x 2	S4  Wall support x 2



STEP 43



These steps are for installing the anti-tip device and securing the cabinet to the wall for safety.

S1  Screw x 2	S3  Wall plug 2 pcs	S4  Wall support x 2
---	---	--

STEP 44




Cable tie 2 pcs

STEP 45

OPTIONS 1


There is 2 ways of installation.




Joint nut 8pcs



Srew 8pcs



Wall plug x 3




Screw x 3




Be careful! At least two people are required

STEP 46


OPTIONS 2



Can be fix on wall separately
on height needed.




①




Screw x 3

②





Wall plug x 3



Be careful! At least two people
are required

Finish

OPTIONS 1



C



Sticker 36pcs

OPTIONS 2

