

## ASSEMBLY INSTRUCTION



### 025 - 702 HAZELTON ROUND DINING TABLE

www.kincaidfurniture.com

Phone : 828-728-3261.

### IMPORTANT NOTES :

- . Place all wooden parts on a clean and smooth surface such as a rug or carpet to prevent the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials, including staples and packing straps before you start to assemble.
- . Do not tighten all screws and bolts until completely assembled.
- . Keep all hardware out of the reach of children.



No.	Dimension	Shape	Quantity
A	Bolt 5/16*38mm		4pcs
B	Flat washer 5/16*Ø16		4pcs
C	Nut 5/16"		8pcs
D	Flat washer 5/16*Ø19		8pcs
E	Lock washer 5/16"		12pcs
F	Allen Key 4mm		1pc
G	Wrench		1pc
H	SCREW (8*38mm)		1pc

**MADE IN VIETNAM**