

The new seeder Instruction for use



Method of use

To adjust: 1, seeds in a box in the first suitable amount of seed, cover cover, adjusted the amount of seeding.

Note: the corresponding types of shaft should be selected according to seed size, each kind of shaft pit have digital (1, 2, 3, 4, 5, 6), can choose the corresponding types of shaft according to the size of the seeds, lots can be according to the sample.

- 2, the depth adjustment: adjust tap according to soil conditions in order to change the way that the seeds buried depth, achieve the goal of emergence and tidy.
- 3, seed depth adjustment after sowing.

The main technical

The weight: 2.5 kg + 0.2 kg

Exterior size: 150 mm x 196 mm x 160 mm

Let quantity: 1.8 kg

Efficiency: 0.03 0.05 (hm/h) 3–5 mu/every day

The number of work: 1

The quality of 3 packets

- 1, without use, no damage in return is that day.
- 2, without using, nondestructive and exchange within two days, once the use of caveat emptor.
- 3, serious custody instructions, instructions for 3 packets of proves.

Product features

- 1, the disseminator is small in size, high precision sowing, the material is excellent.
- 2, change the screw type cap kind of shaft is screwing in type, the shaft replacement more convenient, and prolong service life.
- 3, use on any soil planting (except for paddy field), especially mountainous, hilly terrain more advantage.
- 4, can be used for crops such as corn, soybeans, peanuts, peas, seeding.

Matters needing attention and maintenance

- 1, scraping the kind of leather surface up planting corn, leather down soya beans.
- 2, Seeds coating materials must be dry before it can be installed, had better be used after dry powder mixed with a few fossils, use after a certain period of time to keep clear of in time cave in seed coating agent residue, otherwise the sow is not accurate.
- 3, after use, need to put all the metal parts with antirust oil and placed a cool and dry place preservation.
- 4, the disseminator once use, caveat emptor.