

















INSTALLATION GUIDE


GA6007



PARKLIST


A1		1PC	A2		1PC
B		4PC	C		4PC
E		4PC	F		4PC
G		4PC	H		2PC
I		6PC	J	 M6x15mm	12PC
K		12PC	L		20PC
M		20PC	N		2PC
I	PARTS 	2PC			

1.




A1=1 J=4 K=4 G=2

2.



A2=1 J=4 K=4 G=2


3.



X4


B=4 C=4

4.




I=6

5.



L=20 M=20 H=2 J=4 K=4

6.



E=6 F=4