



























User's Manual
















PRODUCT PARTS:

A	B	C	D	E	F
					
1PC	1PC	1PC	1PC	1PC	1PC
G	H	I	J	K	L
					
1PC	1PC	1PC	1PC	1PC	1PC
M	N	O	P	Q	R
					
1PC	1PC	1PC	1PC	1PC	1PC
S	T	U	V	V1	W
					
1PC	1PC	1PC	1PC	1PC	2PCS
X	Y	Y1	Z		
					
1PC	1PC	1PC	1PC		


HARDWARE:


①	②	③	④	⑤	⑥
					
1/4"x25mm	Ø4x20mm	Ø4x25mm	Ø4x35mm	Ø3x12mm	33x20x20mm
16+1 PCS	4 PCS	20+2 PCS	4 PCS	8 PCS	2 PCS
⑦	⑧	⑨	⑩	⑪	⑫
					
Ø8x30mm			Ø4x12mm	14"x45mm	Ø3x10mm
20+2 PCS	4 PCS	4 PCS	24+2 PCS	2 SET	24+2 PCS
⑬	⑭	⑮	⑯	⑰	
					
Ø6x33mm	Ø15x9mm			5/32"x15mm	
10+1 PCS	10+1 PCS	4 PCS	2 PCS	10 PCS	

STEP 1


⑤  4pcs
Ø4x12mm


⑥  2pcs

⑦  2pcs
Ø8x30mm




STEP 2

⑦  8pcs
Ø8x30mm




STEP 3

⑦  4pcs
Ø8x30mm



STEP 4

⑦  4pcs
Ø8x30mm




STEP 5


- 7



2pcs
- 13




3pcs




STEP 6

- 13




3pcs



STEP 7


11  4SET
14"x45mm





STEP 8

11a  4SET
14"x45mm

12  6pcs
Ø3x10mm




Please make sure that the screw is VERTICAL
so as not to affect the sliding of the drawer.



STEP 9

11a 14"x45mm


12 6pcs
Ø3x10mm



STEP 10


4 4pcs
Ø4x35mm

1 2pcs
1/4"x25mm




STEP 11

- ①  7pcs 1/4"x25mm
- ⑭  6pcs Ø15x9mm




STEP 12

- ①  7pcs 1/4"x25mm




STEP 13



- ⑤  4pcs
Ø4x12mm



STEP 14

- 11b  14"x45mm


- 12  6pcs
Ø3x10mm



STEP 15


11b 14"x45mm

12 Ø3x10mm 6pcs




STEP 16


3 Ø4x25mm 4pcs




STEP 17



STEP 18

- 13  4pcs
Ø6x33mm




STEP 19

- 14




4pcs
- Ø15x9mm



STEP 20


- 15



1pc
- 17




2pcs
- 5/32"x15mm




STEP 21

3  8pcs
Ø4x25mm




STEP 22




STEP 23

- 3  8pcs
Ø4x25mm




STEP 24

- 15  3pcs
- 17  6pcs
5/32"x15mm




STEP 25





2  4pcs
Ø4x20mm





STEP 26




STEP 27



STEP 28




STEP 29



STEP 30


- 9



4pcs
- 10



8pcs
- Ø4x12mm





STEP 31

⑩  16pcs
Ø4x12mm


Three-way adjustable hinge for perfectly aligned doors

1. TO ADJUST DOOR FORWARD OR BACKWARD.
2. TO ADJUST DOOR TO RIGHT OR TO LEFT.
3. TO ADJUST DOOR UP OR DOWN.




STEP 32


⑩⑥  2pcs ⑩⑦  2pcs
5/32"x15mm



STEP 33



STEP 34



IMPORTANT-READ CAREFULLY-RETAIN FOR FUTURE REFERENCE

WARNING:

- Children must stay away from the assembly zone, preventing children from potential asphyxia because of plastic bag and foam breathing in nose;
- For your safety, please do not tread or climb product.
- The loading weight shall be within the range that vendor claims. The product is designed for adults use, domestic use and indoor use only.
- The product shall not combine with other product for use.
- If the product with seat height adjustments with energy accumulators that only trained personnel may replace or repair seat height adjustment components with energy accumulators
- Check regularly that all assembly fastenings are properly tightened, do not use the product if any structural part is broken or missing
- Incorrect installation and incorrect use can cause accidents. Please completely follow the guidance of assembly instruction.

Security instructions:

- Before assembling check whether all parts listed in the parts list have been delivered. Do not start assembling if parts are missing or damaged.
- A failure to assemble this product correctly could cause damage or result in serious injury! Before assembling make sure that you have enough space for the procedure. Assemble on a flat surface.
- Keep the assembly instructions available at all times and follow each of the individual steps exactly.
- During assembly, be careful with all the parts of the assembly (do not walk on them or distort them) and beware of shearing and trapping risks. Keep children and pets away while setting up the furniture.