Instruction Manual

Item# CE134

Mist Fan





Having Trouble?

Call us at

(951) 319-4433

or email at

customerservice@ecintel.com

Monday - Friday 7:00AM - 3:30PM PST

Purchased your product online?

We would really appreciate it if you can share your experience with others by reviewing our product on the website from which you purchased.

☆ ☆ ☆ ☆ ☆

Have Questions or Issues? Need help with assembly?
Contact us and we will resolve immediately.

Support Hours M-F 7:00AM - 3:30PM (U.S Pacific Time)

Call:
951-319-4433

Email:
customerservice@ecintel.com

Purchased your product online?

We would really appreciate it if you can share your experience with others by reviewing our product on the website from which you purchased.



Warranty

Limited 1-Year Manufacturer Warranty on xbrand.us

Manufacturer warranty covers:
• Parts that are deemed defective within 30 day will be shipped free of charge.
• Any warranty claim after 30 days, will require shipping to be paid by the customer.

Any visible damage due to the neglect, misuse, or abuse will void the limited warranty of the product.

For further information, please contact us:
Office Phone: (951) 319-4433
Email: customerservice@ecintel.com

YouTube video instruction

Please use your smart phone camera to scan the QR code. Simply point your camera and let the camera scan the code below, and click on the link that opens up.

https://xbrand.us/product/ce134/

Contents

Contents 2

What is included 3

Assembly instructions 4

YouTube video instruction 5

Warranty 6

What is included



Part No. 11



Part No. 3




Part No. 20




Part No. 4



Part No. 2



Part No. 5



Part No. 7



Part No. 17



Part No. 24



Part No. 19



Part No. 6




Part No. 21




Part No. 16

Assembly instructions


1. Misting Board
2. Front Grill
3. Misting Board Lock Screws
4. Blade Lock Nut
5. Blades
6. Grill Lock Nut
7. Back Grill
8. Motor Shaft
9. Motor Cover
10. Grill Lock Nut
11. Grill Lock Screw
12. Motor Holder
13. Connection Holder
14. Main Holder
15. Holder Fixed Screw
16. Main Body
17. Water Tank
18. Water Outlet Lock nut
19. Base
20. Base Lock Nut
21. Wheels
22. Misting Tube
23. Control Panel
24. Remote Control
25. Decorate Panel
26. Water Indicator



Control panel



Remote control



Indicator light:
1. Natural mode indicator
2. Sleeping mode indicator
3. Oscillation
4. Mist volume indicator: minimum-medium-maximum
5. Timer
6. Speed: low-medium-high
7. Power on indicator

Buttons:
A. On/Off
B. Speed
C. Mode
D. Timer
E. Oscillation
F. Mist