



Important Notes Before Installation




1. Read this full manual thoroughly before assembly and strictly follow all installation steps.
2. Inspect the outer carton for dents, cracks or impact damage upon delivery.
3. After unpacking, verify that all components and hardware are complete, scratch - free and undamaged.




① Pedestal Column × 1







② Tabletop × 1




③ Base Bottom Mount Plate x1



④ Tabletop Mount Plate x1

a	×1	b	×10	c	×6	d	×6	e	×10	f	×7
											
Allen Wrench		Button-head socket cap screw		Flat-head socket cap screw		Button-head socket cap screw		Flat Washers		Adjustable leveling glide	


Installation components



Assemble Pedestal Column & Base Bottom Mount Plate

1. Lay the pedestal column flat on the floor.
2. Align the Base Bottom Mount Plate with the threaded holes at the bottom of the pedestal column.
3. Hand-thread Flat-head socket cap screw (c) into all holes loosely.
4. Confirm the plate sits flush and fully aligned. Tighten all screws evenly using the supplied Allen Wrench (a).

4





Secure Tabletop Mount Plate to Top of Pedestal Column

1. Place Tabletop Mount Plate over the threaded holes on top of the pedestal column, align all holes precisely.
2. Insert 4 pcs Button-head socket cap screw (b) from the top; hand-fasten each screw lightly only.

IMPORTANT WARNING: Do not fully tighten screws now. All 4 screws must be loosely fitted first to avoid plate misalignment.

3. Once all screws are lightly secured, tighten every screw evenly with the Allen Wrench (a).



Mount the Round Tabletop

SAFETY REMINDER: The tabletop is heavy. Two people are required to lift and position it. Do not assemble alone.


1. With assistance, lift the round tabletop and rest it evenly on the pre-assembled pedestal unit.
2. Align threaded holes on the underside of the tabletop with holes of the Tabletop Mount Plate.
3. Fit one flat washer (e) onto each flat-head screw (b), then hand-thread all screws loosely.
4. Tighten all screws evenly one-by-one using the Allen Wrench (a), to avoid uneven table surface.

Final Inspection

1. Re-check all screws to confirm they are fully and evenly tightened.
2. Shake the table gently from all sides; the table should stay stable with no wobble or rattling noise.

Maintenance & Safety Tips

1. Retighten all connecting hardware every 3 months to maintain table stability.
2. Clean surfaces only with a soft, damp cloth; avoid harsh chemical cleaners.
3. Do not stand or place excessively heavy objects on the tabletop.



Leveling Foot Adjustment Guide

This adjustable leveling foot mounts on the bottom of the base to stabilize the table on uneven ground.

1. Screw the feet into the threaded holes at the column base.

2. Rotate the plastic foot to adjust height and stop table wobble.

Note: Installation is optional. The table works fine without these feet.