
Cabinet > Manual



Thank you for purchase on our products. Please contact us if you have difficulty with assembly or need replacement parts. Our customer service is here to assist you.
Please attach your User Name or Order ID so that we can assist you better.

Vielen Dank für Ihren Kauf von uns Produkten. Bitte kontaktieren Sie uns, wenn Sie Probleme mit Montage haben oder Ersatzteile benötigen. Wir Kundenservice ist für Sie da.
Bitte geben Sie Ihren Benutzernamen oder Ihre Bestellnummer an, damit wir Sie besser unterstützen können.

EN

Thank you for purchase on our products. Please contact us if you have difficulty with assembly or need replacement parts. Our customer service is here to assist you.
Please attach your User Name or Order ID so that we can assist you better.

WARNING

Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest shelf.
6. Never allow children to climb or bang on drawers, doors or shelves.

DE


Vielen Dank für Ihren Kauf von uns Produkten. Bitte kontaktieren Sie uns, wenn Sie Probleme mit Montage haben oder Ersatzteile benötigen. Wir Kundenservice ist für Sie da.
Bitte geben Sie Ihren Benutzernamen oder Ihre Bestellnummer an, damit wir Sie besser unterstützen können.

WARNUNG

























Bei unerwarteter Montage oder Verwendung können schwere oder tödliche Verletzung auftreten.

1. Legen Sie in den Montageprozess alle Teile weg von Babys oder Kindern.
2. Stellen Sie sicher, dass der gebohrte Wandbereich frei von verborgenen Stromkabeln, Wasser- und Gasleitungen ist, wenn Sie dieses Produkt an der Wand befestigen.
3. Die Verwendung von Kippsicherungen kann die Gefahr eines Kippens nur verringern, jedoch nicht beseitigen.
4. Setzen Sie bitte keine schweren Gegenstände auf dieses Produkt, es sei denn, dass das Produkt speziell für die Unterbringung konzipiert wird.
5. Legen Sie bitte die schwersten Gegenstände auf das unterste Regal.
6. Erlauben Sie nie Kindern, auf Schubladen, Türen oder Regale zu klettern oder zu knallen.

Parts List(EN) / Teile Liste(DE)





Parts List(EN) / Teile Liste(DE)


A  M6x35mm 62+2PCS	**B**  Ø15x9mm 62+2PCS	**C**  M4x40mm 32+2PCS	**D**  Ø6x30mm 74+2PCS
E  M3x12mm 30+2PCS	**F**  M4x16mm 8+1PCS	**G**  8PCS	**H**  2PCS
I  2PCS	**J**  6PCS	**K**  Ø35mm 8PCS	**L**  Ø35mm 4PCS
M  M3.5x12mm 72+2PCS	**N**  Ø20mm 22+2PCS	**O**  M4x35mm 2PCS	**P**  2PCS
Q  M4x12mm 4PCS	**R**  M3x14mm 36+2PCS	**S**  10+1PCS	**T**  Ø6x50mm 4PCS
U  M5x20mm 4PCS	**V**  28+2PCS	**W**  Ø6x30mm 2PCS	**X**  M4mm 1PC	**Y**  M5x50mm 4PCS
CL  300mm 2PCS	**CR**  300mm 2PCS	**DL**  300mm 2PCS	**DR**  300mm 2PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 1











	**E** x 6PCS
	**CL** x 1PC
	**CR** x 1PC

STEP 2









	**A** x 6PCS


STEP 3



⚠ Turn over part 14 to install the other side.


	**E** x 6PCS
	**CL** x 1PC
	**CR** x 1PC


STEP 4




	**D** x 2PCS

STEP 5




	**H** x 1PC
	**I** x 1PC
	**R** x 4PCS


STEP 6



	**C** x 2PCS


STEP 7





A x 2PCS


STEP 8







D x 5PCS

STEP 9




STEP 10



	C x 2PCS
	**O** x 2PCS


STEP 11






D x 2PCS

STEP 12









B x 2PCS


STEP 13



	**D** x 5PCS


STEP 14






	**B** x 4PCS

STEP 15




	**D** x 2PCS

STEP 16






B x 2PCS




STEP 17



	**D** x 6PCS


STEP 18







D x 2PCS

STEP 19









A x 10PCS

STEP 20









C x 2PCS


STEP 21






	**C** x 6PCS

STEP 22



	**D** x 8PCS


STEP 23






D x 4PCS


STEP 24






A x 4PCS

STEP 25









B x 4PCS


STEP 26







	**B** x 10PCS



STEP 27




	**S** x 10PCS


STEP 28




	**D** x 6PCS
	**H** x 1PC
	**I** x 1PC
	**R** x 4PCS


STEP 29




 **T** x 4PCS


STEP 30






 **A** x 2PCS


STEP 31






C x 2PCS

STEP 32









B x 2PCS


STEP 33






A x 4PCS


STEP 34



C x 2PCS


STEP 35







	**D** x 6PCS

STEP 36






	**B** x 4PCS
	**N** x 4PCS




STEP 37



C x 4PCS


STEP 38






D x 6PCS


STEP 39




	A x 12PCS


STEP 40



	B x 6PCS
	**N** x 6PCS
	**X** x 1PC




STEP 41




	**D** x 6PCS

STEP 42



	B x 6PCS
	N x 6PCS
	X x 1PC


STEP 43







D x 6PCS

STEP 44









A x 6PCS


STEP 45




	B x 6PCS
	N x 6PCS




STEP 46







D x 4PCS

STEP 47










A x 6PCS


STEP 48



	Y x 4PCS
	**X** x 1PC

STEP 49










B x 6PCS

STEP 50




	**C** x 10PCS


STEP 51






	**D** x 4PCS

STEP 52









	**A** x 10PCS
	**F** x 2PCS
	**G** x 2PCS


STEP 53







	**B** x 10PCS

STEP 54










	**E** x 12PCS
	**DL** x 2PCS
	**DR** x 2PCS


STEP 55











STEP 56







	**U** x 4PCS


STEP 57

	**E** x 2PCS
	**F** x 2PCS
	**G** x 2PCS
	**J** x 2PCS
	**L** x 4PCS
	**M** x 8PCS





STEP 58




	**M** x 16PCS

STEP 59



	E x 4PCS
	F x 4PCS
	G x 4PCS
	**J** x 4PCS
	**K** x 8PCS
	**M** x 16PCS


STEP 60





	**M** x 32PCS


STEP 61

Lock the long side of the " P " L-shaped metal plate to the ① board with the " Q "short screw.







	**P** x 2PCS
	**Q** x 4PCS
	**R** x 28PCS
	**V** x 28PCS


STEP 62


Drill 2 holes on the wall at the required position for anti-falling device installation.

WALL









	**W** x 2PCS

STEP 63

Move the cabinet to the required position, use the " C " long screw to fix the cabinet to the wall.

WALL






	**C** x 2PCS


The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.


Components Name



Obvious gaps between doors or Doors don't look closed



1 Turn "internal & external screw" to the right can make the door approach inside.
Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right Slightly.


2 Push the door to the cabinet




3 Rotate the "front and rear screws" to the right




When door is leaning




1 Turn "internal & external screw" to the left can make the top of the door tilted outward.







1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




1 Turn "up & down screw" to the left



2 Lower the door's height so that 2 doors are of the same height.



3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2

⚠ WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **ALWAYS install Anti-tip device provided.**
- **NEVER put a TV on this product.**
- **NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.**
- **NEVER open more than one drawer at a time.**
- **Place heaviest items in the lowest drawers.**

This is a permanent label. Do not remove!

Made in China