
Installation & Assembly




Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2
ESTIMATED ASSEMBLY TIME: 1 HOUR

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Back panel must be used to make sure your unit is sturdy.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.



Before You Start








- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.


Board Identification

Not actual size




A

SIDE PANEL
Qty:2




B1

LEFT BACK PANEL




B

MIDDLE BACK PANEL




B2

RIGHT BACK PANEL




C1

LEFT DOOR




C2

RIGHT DOOR



D

TOP




E

LEG
Qty:2


F

BOTTOM




G

SIDE ADJUSTABLE SHELF
Qty:2




H

PARTITION
Qty:2




I

MIDDLE ADJUSTABLE SHELF



J

BOTTOM SUPPORT




K

FRONT RAIL

Board Identification


Not actual size



Hardware Bag Reference number:


Part List

Actual Size




① x26

SCREW
TDM0024
spare: 2




② x8

SCREW
TDM0055
spare: 2




③ x4

BOLT
TDM0056



④ x4


BOLT
TDM0004
spare: 2



⑤ x4

WASHER
TDM0005
spare: 2

Not Actual Size




⑥ x2

HANDLE
TDM0026




⑦ x12

SHELF SUPPORT
TDM0007
spare: 2




⑧ x4

METAL PLATE
TDM0066




⑨ x4

WHEEL
TDM0057




⑩ x4

PIN
TDM0058



⑪ x3

WIRE GROMMET
TDM0060




⑫ x1

WARNING LABEL
TDM6570


STEP 1


- Attach (A) to (E) as below shown.



STEP 2


- Attach (B1) & (B) & (B2) to (A) & (E) as below shown.






STEP 3

- Attach (F) to (A) & (B) & (E) as below shown.




STEP 4

- Attach (D) to (A) & (B) as below shown.




STEP 5


- Attach (H) to (D) & (F) as below shown.




STEP 6


- Attach (G) & (I) to pre-assembled unit as below shown.






STEP 7







② x8



③ x4




⑨ x4



⑩ x4


- Attach (9) & (10) to (C1) & (C2) as below shown.





x2


Push and bend the tab.

STEP 8










- Attach (6) to (C1) & (C2) as below shown.





x2

Push and bend the tab.

STEP 9


- Attach (C1) & (C2) to pre-assembled unit as below shown.







STEP 10


- Attach (J) to (E) as below shown.




STEP 11








- Attach (8) to (A) & (E) as below shown.
- Attach (K) to (J) & (E) as below shown.



Maximum Loads

This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.



Apply the warning label to the center of the top panel as shown, ensure the TV covers the label in use. You will not be able to remove the label after it is applied to the top panel.