HOFFREE

Hoffree,Provide the best office and home
environment to you.

🛒 URL:http://www.hoffree.com

✉ Email:service@hoffree.com

MADE IN CHINA

Gaming Chair

User Manual

WHO ARE WE?

Hoffree is a brand that helps users enjoy life better.
Its slogan is Hoffree,Provide the best office and home environment to you.

Our purpose is to create a comfortable office environment.

Through our efforts, we have a strong and stable design and production team. At present, gaming chair, computer desk, bookcase and other products of Hoffree have become one of the hot products in the market.

HOFFREE

Hoffree,Provide the best office and home environment to you.

Please believe that we can further improve our products and services with your accompany, so as to provide better customer experience.

Product specification

|	
Brand:Hoffree	Product Dimensions:23.62x23.62x52.28in
Product Name:Gaming Chair	The Name Of The Bluetooth : HuaBox
Product Weight:70lb	Working power Supply: 5V/2A
Weight Capacity:450lb	charging pad as the main power supply
Effective Distance:32ft	

⚠ ATTENTION

Some screws are pre-installed on the chair and are NOT included in the hardware pack.

Please check the screw number according to the instruction manual and look for it on the chair!

HOFFREE

Please remove the pre-installed screws before installation

1

B×1

2

3

PACKING LIST

A*1	B*1	D*1	E*1	F*1
G*5	R*1	Y*2	T*1	C-R*1
C-L*1	H*4 6*20mm	P*3 6*40mm	J*4 8*40mm	X*4 6*25mm
S*2 6*30mm	W*1 5x10mm	L*1	K*1	M*2
N*1	Q*4	Z*1	V*1	

INSTALLATION

1

E×1
F×1
G×1

2

L×1
S×2
T×1
R×1

3

X×4
Y×2
B×1

4

W×1
H×4
D×1

Note: All screws havebeenpreassembledto theaccessories Please remove them from the accessories before assembling

INSTALLATION

5

6

A×1

P×3

K×1

7

8

M×1

N×1

C-R×1

C-L×1

J×4

Q×4

V×1

Note: All screws havebeenpreassembledto theaccessories Please remove them from the accessories before assembling

FUNCTIONS OF EACH BUTTON

(power)	**ON&OFF**	
SPEED+ SPEED−	**Speed adjustment**	SPEED+
AUTO− MODE+	**358 fliker patterns to change**	AUTO− AUTO MODE+
(bright) (dark)	**Brightness adjustment**	SPEED−
(lock)	**LOCK** **Match:** Press and hold "LOCK" for 5 seconds until green strip flash 3 times. **Cancel the match:** Press and hold "LOCK" for 5 seconds until white strip flash 3 times.	(lock) W (setting) R G B Y C P 🛜 RF Wireless
AUTO	**Auto mode** Press to play automatically 358 modes. Press 5 times to enter color RGB mode **Single cycle play** Under AUTO mode, press "SETTING" once, then press "LOCK" once to cyclic the current pattern.	
(setting)	**SETTING** Adjust the LED quantity: Press and hold for 5 seconds until white strip flash to enter the setup menu. Press MODE +/- to adjust the quantity of the LED light.Press "SETTING" to finish the setting.	
W R G B Y C P	**Static Monochrome Mode** White,Red,Green,Purple,Yelow,Blue,Pink	

Long press the setting key to enter the setting mode

MODE+/− adjust the lighting part (left/right side of backrest/entire seat cushion)

SPEED+/− to adjust the number of lamp beads (cannot be adjusted when the light strips are fully on, only when part of the light strips are on, the number of lamp beads can be increased or decreased)

USAGES

Testing	Continuously press "AUTO" 5 times to enter the RGB automatic switching mode,which can test the your LED.
Matching	Press "LOCK" for 5 seconds until LED flash in green quickly to match the remote control with the receiving controller. Press "LOCK" for 5 seconds untill LED flash in white slowly to un-match.
Reorder RGB	Different kinds of LED,the RGB keys may don't perfectly match to your LED, reorder them if needed. Continuously press "SETTING" 5 times until LED flash in white once and then turn into all white, press the "R" until LED is red, press "G" until LED is green, press "B' untill LED is blue, finally press "SETTING" once to finish your setting.
Adjust the LED quantity	Press "SETTING" for 5 seconds until LED flash in white to enter the setup menu. Press "MODE +/-" or "SPPED+/-" to add/reduce the quantity of the LED pixels.Finally press "SETTING' once to finish the setting.

TROUBLESHOOTING

Fault conditions	Possible causes	Exclusion method
The product is shaking and unstable	1. Wrong screw installation 2. The screw is broken 3. Check that the screws are not tightened in place	1. According to the instruction manual, install the correct screw in the correct position 2. To replace, use the included spare screws 3. Tighten the loose screws
The light strip is off	1. Not plugged in 2. The lighting pattern is not saved correctly	1. Confirm that the product is powered on normally 2. Please read the instructions of the remote control carefully (page 6), and follow the operation
Audio doesn't work	1. Bluetooth connection failed 2. Bluetooth connection error	1. Turn on your phone's bluetooth to connect 2. Turn off the phone's Bluetooth and reconnect (Bluetooth name: HuaBox)
Remote control not working	1. The remote control gasket is not pulled out and cannot work 2. The battery is in poor contact or the battery is installed backwards 3. The battery is dead	1. Check whether the remote control gasket is pulled out 2. Check whether the battery is installed incorrectly and adjust 3. Replace the new battery to make the remote control work normally

WARRANTY & SUPPORT

Thanks for purchasing our product. For any advice about the product or wanna know other products of *Hoffree*.
Please visit *Hoffree* official website www.hoffree.com or Amazon.
Your purchase and support will be our driving force!