
Bookshelves

Assembly Instructions - Please keep for future reference

1061030298B

1061030299B



Dimensions

Width - 31.5inch
Depth - 15.3inch
Height - 69.8inch

Important – Please read these instructions Eully beEore starting assembly

Issue 1 - 05/11/23

SaEety and Care Advice

Important – Please read these instructions Eully beEore starting assembly

• Check you have all the components and tools listed on the Eollowing pages.

• Remove all Eittings Erom the plastic bags and separate them into their groups.

• Keep children and animals away Erom the work area, small parts could choke iE swallowed.

• Make sure you have enough space to layout the parts beEore starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its Einal position (in the same room) as possible.

• Assemble on a soEt level surEace to avoid damaging the unit or your Eloor.

• Parts oE the assembly will be easier with 2 people.



• To reduce the likelihood oE damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• Erom time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you Eully tighten the bolts

• Regularly check and ensure That all bolts and Eittings are tightend properly.

WARNING
In order to help prevent overturning – please Eollow these instructions

To help prevent product toppling over please Eollow the below steps:-

Use the anti tip stap or wall Eixing method provided (iE applicable)
Do not allow children to climb or hang on the Eurniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top oE the Eurniture, unless the Eurniture has been designed Eor this purpose

please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable Eor your wall type

Components - Panels

Please check you have all the panels listed below



1 (1645X50X15mm)X1




2 (1645X355X15mm)X1




3 (1645X50X15mm)X1




4 (1645x355X15mm)X1




5 (728x370X15mm)X1




6 (728X354X15mm)X1




7 (660x50X15mm)X1




8 (738x300X2.7mm)X2




9 (738x347X2.7mm)X3




10 (85X50X50mm)X4




11 (660X45X15mm)X2




12 (265x45X15mm)X2




13 (790X385X15mm)X1




14 (800X390X24mm)X1



15 (726X336X15mm)X2



16 (585X326X15mm)X1








17 (585X326X15mm)X1

Components - Eittings

Please check you have all the panels listed below


Note: The quantitie below are the correcet amount to complete the assembly. In some cases more Eittings may be supplied than are required.

A  Male Camlock x 49	**B**  Eemale Camlock x49	**C**  Dowel (8x30) x 34
D  Door Hinge x 4	**E**  4*14mm Screw x 20	**F**  3*17mm Screw x 16
G  Plasticwedge x 16	**H**  6*35mm Screw x4	**I**  ShelE Support Pin x 8
J  Handle & Eixings x 2	**K**  Magnet Touch x 2	**L**  3*14mm Screw x 4
M  Wall Eixing Pack x 2	**N**  Ø20 Sticker x 22	**O** 726mm x 2
P  Protective Feet x 4		



Phillips screwdriver
(medium & large)

Ruler - Use this ruler to help correctly identiEy the screws





The screws length is measured Erom the head to the point (30mm screw shown).


Using Camlocks

Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the Eemle camlock as shown in the instruction.

Note：ensure that the arrow on the top oE the camlock points towards the entry hole Eor the male camlock.

3




Step 4

Turn the Eemale camlock clockwise with a screwdriver.


You should Eeel a click when the camlock is locked in place.

The joint is now secure.

4




Assembly Instructions




Assembly Instructions

Step 1




Step 2




Assembly Instructions

Step 3





Step 4




Assembly Instructions


Step 5






Step 6






Assembly Instructions

Step 7




Step 8




Assembly Instructions


Step 9









Step 10




Assembly Instructions


Step 11






Step 12







Assembly Instructions


Step 13





Step 14






Assembly Instructions

Step 15

A

A x 8




X4

Step 16


B


B x 8




Assembly Instructions


Step 17






Step 18







Assembly Instructions


Step 19









Step 20




Assembly Instructions

Step 21







Step 22




Assembly Instructions


Step 23






Step 24









Assembly Instructions


Step 25

I

K x 8







Step 26

J


J x 2

L

L x 2


K

K x 2




Assembly Instructions

Step 27



Step 28





Assembly Instructions


Step 29


F


H x 16

G

I x 16









Step 30

N

N x 22





Assembly Instructions


Step 31





M x 2





ATTENTION:
For safety and stability, we suggest you to secure the anti tip accessories to the wall to prevent tipping, injury, and property damage.














Assembly is complete.

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for **supporting your unit. Consult a qualified tradesperson if you** are unsure.


Hints:

1: General rule: always use a larger screw and wall plug if you are not sure.
2: Ensure you use the recommended drill bit to match the wall plug and hole size.
3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 “General Purpose” wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 “Cavity Fixing” wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 “Hammer Fixing” wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 “ Plasterboard” wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 “ Cavity Fixing – Heavy Duty” wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 “ Shield Anchor” wall plug – heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.

Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.