210 mm

INSTRUCTION MANUAL



Laguna Poly Garden 48" Backless Bench
SKU: OP2001-BN

V 1.0

142 mm

NOTICE

Do not overtighten screws. (Insert all screws before tighten screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.

TOOLS REQUIRED

ALLEN WRENCH (PROVIDED) | WRENCH (PROVIDED)

BENCH 660 LBS CAPACITY | 1 PERSON ASSEMBLY | UP TO 30 MIN. ASSEMBLY

HARDWARE



PARTS



PARTS



PRODUCT ASSEMBLY

1 Attach part C Bench Rail to 2 PCS of part B Bench Legs with 2 PCS of part 1 Bolt.

Do the same to another Bench Rail and the other two Legs.

Do not tighten bolts too much at this stage.



PRODUCT ASSEMBLY

2 Attach the combined legs (part C+B+C) to part A Bench Top with 4 PCS of part 2 Bolt, part 4 Washer and part 5 Nut.



3 Attach another combined legs (part C+B+C) to part A Bench Top with 4 PCS of part 2 Bolt, part 4 Washer and part 5 Nut.



PRODUCT ASSEMBLY

4 Fix 4 PCS of part D wooden corners to the combined legs (part C+B+C) and the rail of part A Bench Top with 8 PCS of part 3 Screw as below.



5 Tighten all the bolts and nuts again for your secure usage.

Thanks for purchasing this bench, enjoy it.