

ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION# 24-05-20

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**
  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**
  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**
  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**
  Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

ROUND TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

P1 - 1PC




TABLE TOP

P2 - 4 PCS




TABLE LEG

HARDWARE

H1 - 16 PCS




M6x40 JCBC SCREW

H2 - 16 PCS




SPRING WASHER

H3 - 16 PCS



FLAT WASHER

H4 - 8 PCS



WOOD DOWEL

H5 - 8 PCS






LEG GLIDE


H6 -1 PC



ALLEN KEY



Carton	Designation	Part List		Hardware List
	Table Top	P1		 H1 x 16**pc**
				M6x40 JCBC SCREW
	TABLE LEG	P2		 H2 x 16**pc**
				Spring Washer
				 H3 x 16**pc**
				Flat Washer
				 H4 x 8**pc**
				Wood Dowel M8x30mm
				 H5 x 8**pc**
				LEG GLIDE
				 H6 x **1pc**
				Allen Key




ASSEMBLY INSTRUCTIONS

PARTS LIST

NO.	COMPONENT	QTY.
P1	TABLE TOP	1
P2	TABLE LEG	4

HARDWARE LIST


NO.	DESCRIPTION	QTY.
H1	M6X40MM JCBC SCREW	16
H2	SPRING WASHER	16
H3	FLAT WASHER	16
H4	WOOD DOWEL M8 x 30mm	8
H5	LEGS ADJUSTABLE GLIDE	8
H6	ALLEN KEY	1



COMPLETE ASSEMBLY


*** MALLET (NOT PROVIDED)**

While preparing the Table Top (P1) by placing it upside-down on a flat soft & clean surface .



STEP 1

H4 x 8 M8 x 30mm




STEP 2

H1 x 16	M6 x 40mm
H2 x 16	
H3 x 16	

Assemble the third Table legs (P2) by attaching it to the connecting blocks in the Table Top, and make sure the locating wooden dowels in the table leg are snug in the holes at the table top.

Then, Align Bolt (H1) fitted with a Spring Washer (H2) & a Flat Washer (H3) through the holes in the connecting blocks, respectively.


Tighten the bolts using the Allen Key (H6).



STEP 3

Align the Legs Adjustable Glide (H5) into nuts in the Table Leg Base .

H5 x 8




CAREFULLY PUT THE TABLE UPRIGHT BY TWO OR MORE ADULTS PEOPLE .

CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use .

CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.