Instruction Manual – Safety Gate

Safety instructions

"IMPORTANT!THE FOLLOWING INSTRUCTIONS MUST BEREAD CAREFULLY AND KEPTFORFUTUREREFERENCE." WARNING: Incorrectinstallationcan be dangerous.WARNING- The safety gate must not be used if individual parts are damaged or lost. WARNING- The safetygate must not be attachedto windows. WARNING: Never usewithout wall mounting plate. Caution:For household use only.

Before assemblingand using the stair gate, pleaseread all the information below, as failureto follow these warningsand instructions could result in seriousinjury or even death.

• To prevent serious or fatal injuries, the safety gate must be installed securely and used according to the manufacturer's instructions.

• Never use the safety gate if a child can climb over it or open the gate.

• Never leave the child unattended.

• This product may not necessarily prevent all accidents

• Use it only when the locking mechanism is securely engaged

• This product is suitable for children aged 6-24 months or small to medium-sized pets.

• Incorrect installation or positioning of the gate can be dangerous.

• Never release the handle while the gate is retracting.

• This safety gate MUST NOT be installed over window openings or similar.

• Check the child safety gate regularly for the safety of the attachments and stability. DO NOT use the safety gate if any parts are damaged or missing

• Do not install it near heaters or other sources of heat.

• Always make sure the gate is locked after closing.

• If the barrier gate is used at the bottom of a staircase to prevent the child from climbing up the stairs, it must be attached to the bottom step.

• If the gate is used at the top of the stairs to prevent the child from falling down the stairs, it MUST be positioned 20 cm behind the top step





• The stair gate must be mounted between rigid surfaces such as plasterboard, wood, or a solid wall.

• Children can suffer severe injuries or even die if the stair gate is not securely installed

• Always install and use the safety gate as instructed and use all included parts.

• You MUST attach all fasteners to keep the door gate in its position. Without fasteners, the child can push it out and escape

• NEVER use this safety gate to keep children away from the swimming pool

• This product may not necessarily prevent all accidents

• No modifications may be made to the child safety guard

• No additional parts may be attached • The gate closes automatically

Special Reminder

Optional for Pressure Mounted and Hardware Mounted, Two installation methods, you can choose any one

Pressure Mounted	Hardware Mounted



METHOD A



METHOD B

Part List

1. Safety Gate
2. Door Handle
3. Clamping Screw
4. Rubber Pad
5. Spanner
6. Frame
7. Lower Locking Mechanism



AssemblyInstructions

1. Measure the width of the opening to which you want to attach the safety gate. For widths over 85 cm, select the appropriate extension:



Width：75cm/29.5"-82cm/32.3"



Width：85cm/33.5"-92cm/36.2"



Width：95cm/37.4"-102cm/40.2"



Width：105cm/41.3"-112cm/44.1"

2. Use with extension: Insert the long end of the extension pin (F) into the grille frame (E) and the short end into the extension (H). The clamping screw (G) can then be attached to the extension:





3.Tighten both of the Tension Knobs by turning them clockwise at the same time.
Note: make sure that the bottom of the Gate Frame remains completely flat on the floor.
Ensure gate is securely fastened at both top and bottom.





Using the safety gate

a. Opening the door: push the botton forward and upward press to open it.