Product size:
L100*W100*H50/68cm



The intended use of this product is for domestic use only.

Important, please retain for future reference.

Read carefully.

Before you start

⚠ Warnings

IMPORTANT, RETAIN FOR FUTURE REFERENCE READ CAREFULLY

See enclosed instructions for assembly, safety and care information.

Failure to follow the warnings could result in serious injury.

Handle heavy parts with care.

Ensure that this product is fully assembled as illustrated before use.

This product should only be used on firm, level ground.

Keep small parts out of reach of children.

Do not stand or climb onto this product.

This product is intHeaded for **domestic use** only.

Ensure the table is always placed on level ground.

Furniture can be dangerous if incorrectly used. No liability will be accepted for damage or injury caused by incorrect use of this product.

✓ Dos

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap all packaging materials and place the components on suitable surface to prevent scratching your product.

Check the pack and make sure you have all of the parts listed. Check all screws and bolts and tightened and inspect regularly. In the event of problems or missing parts, please contact the seller.

We recommHead the use of furniture covers to protect your product
when not in use.

During bad weather or in winter months, the product should be stored in a cool, dry place. Before storage, ensure that the product is clean and dry.

To clean, wipe down with a sponge and warm soapy water and wipe with a clean, dry cloth.

When cleaning glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substances containing abrasives since these substances scratch glass.

✘ Don’ts

Do not stand or climb onto the product.

Do not use power tools to construct this product.

Do not sit or lean onto the rims of this product.

Do not use this product if parts are missing, damaged or worn.

Never use scourers, abrasives or chemical cleaner.

Do not use this table as a ladder as this could lead to the table becoming unbalanced and overturning.

Do not place very hot or very cold items on the glass surface unless adequately thick table-mats are used to prevent such items from coming into contact with the glass.

Do not use the glass as a chopping surface. Do not strike glass with hard or pointed items.

Never drag furniture when moving it, always lift it.

Number of people required for assembly

Two people

Time to assemble

50 Minutes

Tools required



Tips:

It is best not to fully tighten the nuts and bolts until they are all correctly located. Only carefully tighten them when you are satisfied with the alignment of all components.
Be careful not to overtighten.

Components, fixtures & fittings (not actual size)

Parts List					
Part No.	Diagram	Qty.	Part No.	Diagram	Qty.
A	 Table Top Frame	1 PC	B	 Small Base	4 PCS
C	 Big Base	1 PC	D	 Glass Top	1 PC
W20	 M6*20mm Bolt	4 PCS	F3	Washer	4 PCS
F2	 Bolt Head Cap	4 PCS	S1	 Spanner	1 PC

Step by step assembly instructions

All Bolt Head Caps should not be attached before finally tightening all Bolts with Spanner.

Step One

Place the Glass Top (D) on a soft, level surface.
With the help of another person, place Table Top Frame (A) upside down onto a flat, non-abrasive surface to avoid scratching the surface or rim.



Step Two

Assemble the Small Base (B) onto the Table Top Frame (A) using Washers (F3), Bolts (W20) and Bolt Head Covers (F2).



Before attaching the Bolt Head Covers, tighten all bolts with Spanner (S1).

Step Three

With the help of another person, carefully lift Glass Top (D) and place it onto the Table Top Frame (A).



Step Four

To use Dining Table function, insert the Small Base into the upper Slots on the Big Base (C).

Your Dinging Table is ready for use!



Step Five

To use in the Coffee Table function, take off the table top and turn 90 degrees, then replace the Small Base into the Bottom Slots on the Big Base (C).



This table should be operated by adults.

Children should be kept away during the table function change process between Dining Table and Coffee Table function.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE