
ITEM NO.ZX0187



NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.

MAINTENANCE AND WARNINGS


Thank You For Choosing Our Furniture.
Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :
This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS


Installation:
60 minutes.


Two Person



Before You Start

Please follow the steps below:

- Unbox the package and check if all parts and accessories are complete.
- If you find something missing, stop assembly and contact your supplier immediately.
- Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- NOTE:Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty

We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.


Are you having dificulty with assembly? Missing parts? Please send email with your order number to HKXIMU2026@126.COM

For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance


- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis,or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.

Exploded Diagram




Parts List

A ×1




Top panel

B ×1




Bottom panel

C ×1




Left side panel

D ×1




Right side panel

E ×1




Middle panel

F ×2




Adjustable Shelf

G ×1



Back panel

H ×4



Legs


I ×1



Mid-leg


Parts List

J ×1




Left door

K ×1




Middle Left door

L ×1



Middle Right door

M ×1



Right door




Hardware Liste

1 ×16+1




Screw
Ø6*25mm

2 ×2




Magnetic catch

3 ×4




Hinge

4 ×4



Hinge

5 ×30+3



Screw
Ø3*15mm

6 ×48+4



Screw
Ø4*15mm

7 ×8



Shelf pin

8 ×4




Screw
Ø4*39mm

9 ×4



Wall anchor

10 ×2



Tie

11 ×4



Anti-tip
component

12 ×4



Screw
Ø4*20mm

13 ×1




Screwdriver

14 ×1



Allen key

16 ×4



Hold hands

17 ×8




Screw
Ø4*22mm

Assembly Instructions

Step 1

1.Install leg H/I on of bottom panel B, ensure the corresponding holes are aligned and fix with bolt 1, then tighten the bolt with an Allen key 14.


1	x 16	Ø6*25mm
14	x 1	Allen key



Step 2

1.Insert panel (C/D/E) into the corresponding hole of bottom (B), make sure all holes aligned and use allen key (14) to tighten it as picture show.


14	x 1	Allen key



Step 3

1.Use screw (5) to attach magnetic catch (2) to the corresponding hole of panel (A), tighten screw with screwdriver (13).


2	 x 2	Magnetic catch
5	 x 4	Ø3*15mm
13	 x 1	Screwdriver




Step 4

1.Install the top panel (A) into the corresponding holes in the pre-assembly step 3, make sure all the holes line up and tighten it with (14) allen key as shown in the picture.

14	x 1	Allen key







Step 5


1.Install part (G) into the preassembled step 4, make sure all holes aligned and use screw (8) to attach them, tighten screw (5) with screwdriver (13).


5	x 26	Ø3*15mm
13	x 1	Screwdriver



Step 6








Attention:
Before the next step, adjust the feet of the locker to keep it level.

Step 7

1.Insert shelf holder (7) to the unit pre-assembled at step 6 and attach the part (F) to them.


7	x 8	Shelf pin



Step 8

1.Use screw (6) to attach the hinges (4) to door panel (J)&(M)，tighten screws with screwdriver (13)
2.Use screw (6) to attach the hinges (3) to door panel (K)&(L)，tighten screws with screwdriver (13)


6	x 16	Ø4*15mm
3	x 4	Hinge
4	x 4	Hinge
13	x 1	Screwdriver




Step 9

1.Use screw (6) to attach door (J&K&L&M) to pre-assemble unit at step 8 ,tighten screw (10) with screwdriver (13) .
2.Use bolt (16) to attach handle (16) to door panel (J&K&L&M)，tighten bolts with screwdriver (13)


16		x 4	Hold hands
17		x 8	Ø4*22mm
6		x 32	Ø4*15mm
13		x 1	Screwdriver




Concealed hinges are three-way adjustable:




Horizontal
by screw adjustment!




Concealed hinges are three-way adjustable:




In-and-out
by loosening the hinge arm mounting screw or via cam adjustment!



Concealed hinges are three-way adjustable:



Vertical via slots in
the mounting plate
or via cam adjustment!




Hinge adjustment method

Scan for adj video

Step 10

1.Use screw (12) to attach Anti-tip component (11) to panel (G), make sure all holes aligned and tighten screw (12) with screwdriver (13).


12	x 4	Ø4*20mm
11	x 2	Anti-tip component
13	x 1	Screwdriver




Step 11


1.Install Anti-tip device (11) to the wall in this step.

11	x 2	Anti-tip component
8	x 4	Ø4*39mm
9	x 4	Wall anchor
13	x 1	Screwdriver






1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device (6) to the wall with screws (3)

Step 12

1.Let the plastic belt (10) pass through the both part (11) and pull tightly.

10	x 2	Tie

⚠WARNING





Children have died from furniture tipover.To reduce the risk of furniture tipover:

-ALWAYS install anti-tip device provided.
-NEVER put a TV on this product.
-NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
-NEVER open more than one drawer at a time.
-Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!

