


COFFEE TABLE


User Manual




AJ-DJ505648










Warning : Please read this instruction manual carefully before using the product.

version: 2.0

Package Contents

Plates and iron components	Assembly tool kit	Instruction manual


Precautions




1.Avoid long-term direct sunlight exposure




2.Stay away from fire




3.keep away from sharp objects




4.Keep infants/children away from assembly parts to avoid choking and suffocation.




5.keep away from corrosive substances



6.Pay attention to avoid cver-tightening fasteners, orthey may induce cra-cking within the board.



7.Prevent objects from being damaged by immersion in water




8.Prevent object collision and damage




9.Be careful to avoid collisions

Installation of Cams and Pins













Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening o the hole of the pin it is locking. Lock the cam by tturning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.











Disassembly Diagram











Parts List

1 	2 	3 
4 	5 	6 
7  X1	8  X2	9  X2
10 	11 	12 

Parts List


13  X2	14 	15 
16 	17  X2	18  X2
19  X2	20  X2	21 
22  X1		

Tool sheet

A Ø6x35MM  X40+3	B Ø15x10MM  X40+3	C Ø6x30MM  X39+3	D Ø5x40MM  X44+3
E M5x10MM  X14+1	F  300mm X2	G  X8+1	H M3.5x12MM  X18+2
I  X1	J  1M X1	K M4 M3  X1	L  X2
M  X8+1	N M4x15MM  X4		

ASSEMBLY INSTRUCTION


Step 1



Pay attention to the position of hole No. 11 and the large opening of the slide rail.

F	x1
F1 F2	
H	x4
ϕ3.5x12mm	

Step 2





A	x6
ϕ6x35mm	

ASSEMBLY INSTRUCTION

Step 3


The holes of No.14 and No.11 plates are upward.






C	x1
	
ø6x30mm	
B	x2
	
ø15x10mm	

Step 4






B	x4
	
ø15x10mm	


ASSEMBLY INSTRUCTION

Step 5



F	x1
F1 F2	
H	x4
ϕ3.5x12mm	


Step 6




A	x8
ϕ6x35mm	

ASSEMBLY INSTRUCTION

Step 7







C	x2
ϕ6x30mm	

B	x8
ϕ15x10mm	

Step 8






A	x10
ϕ6x35mm	


ASSEMBLY INSTRUCTION

Step 9



C	x8
ϕ6x30mm	


Step 10



B	x10
ϕ15x10mm	

ASSEMBLY INSTRUCTION


Step 11




C	x4
	
ϕ6x30mm	


D	x8
	
ϕ5x40mm	

Step 12






Please note that multi-person collaboration is required.

C	x6
	
ϕ6x30mm	


ASSEMBLY INSTRUCTION

Step 13



D	x8
ϕ5x40mm	


Step 14



A	x8
ϕ6x35mm	


ASSEMBLY INSTRUCTION

Step 15



C	x2
ø6x30mm	
B	x4
ø15x10mm	


Step 16



C	x2
ø6x30mm	
B	x4
ø15x10mm	


ASSEMBLY INSTRUCTION


Step 17



C	x8
	
ϕ6x30mm	

Step 18




D	x12
	
ϕ5x40mm	

ASSEMBLY INSTRUCTION


Step 19

Both sides can be installed



C	x6
ϕ6x30mm	


Step 20



D	x8
	
ϕ5x40mm	


ASSEMBLY INSTRUCTION

Step 21



H	x2
ϕ3.5x12mm	
I	x1
3m	
M	x8

Step 22




E	x4
M5x10mm	

ASSEMBLY INSTRUCTION

Step 23







E	x10
	
M5x10mm	

ASSEMBLY INSTRUCTION

Step 24


X2



D	x8
	
ϕ5x40mm	


Step 25

X2




ASSEMBLY INSTRUCTION

Step 26



A	x4
ø6x35mm	


Step 27




L	x1
N	x2
M4x15mm	
B	x4
ø15x10mm	


ASSEMBLY INSTRUCTION


Step 28



F	x1
	
H	x4
	
ϕ3.5x12mm	


Step 29



A	x4
	
ϕ6x35mm	


ASSEMBLY INSTRUCTION


Step 30



L	x1
	
N	x2
	
M4x15mm	
B	x4
	
ø15x10mm	


Step 31



F	x1
	
F4	F3
H	x4
	
ø3.5x12mm	

Step 32


Note that these two drawers are different and cannot be swapped





ASSEMBLY INSTRUCTION

Step 33


Tear off the tape and apply it to the plate,Then press it firmly with your hand







G	x8
	
J	x1
 1m	


Step 34







Tear off the transparent film from panels No. 1, 4, 6, 7, and 22.



Customer Service

3-years Warranty



We guarantee your product is free from defects in product material and workmanship for three(3) years starting from the date of purchase during normal use of household conditions.If your appliance fails to operate properly within our warranty period,We will send the corresponding accessories,Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours
	Having issue(s) while reading the instruction or completing the assembly.	Feel free to contact us and we will get back to you within 24 hours.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it.We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of somescrew holes.	Feel free to contact us and we will get back to you within 24 hours.
	The screw holes on the wooden board and other wooden boards are not aligned.	1.Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjust the wooden board and board.Until the holes are arranged neatly, then tighten all screws
	Desktop misalignment and unevenness	1.Please tighten the screws connecting the table board to the elevator by 70%, do not tighten them completely. 2.Adjust to a flat and aligned desktop, then tighten the screws. 3.If your problem still can't be solved, please feel free to contact us.
Metal acce-- ssories	Metal accessories are damaged, rusted, bent, and broken.	Feel free to contact us and we will get back to you within 24 hours.
	The table is unstable after being assembled.	1.Check if the screws are tightened. 2.Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3.If your problem still can't be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it.We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.