CARE AND MAINTENANCE
Store outdoor furniture indoors or cover well when not in use.
Remove wooden furniture from standing water. Dust regularly with small brush or vacuum
Spills should be taken care of immediately before they harden or
stain with a slightly dampened sponge.

NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item
* This item should be assembled on a soft surface to prevent scratching the finish during assembly
* This item may require periodic tightening

Weight Capacity : 600 lbs
Warning : Do not stand on chair
Warning : Do not over torque bolts / screws

⚠️ ⚠️ WARNING ⚠️ ⚠️

Product Dimensions:29.13" W x 54.72" D x 27.16" H

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Leg Frame		4X
B	Back frame		1X
C	Side frame		1X
D	Seat Frame		1X
E	Cushion Seat		1X
F	Cushion Back		2X
F1	Cushion Side		1X
G	Pillow		1X
H	Bolt	M8x65	12X
I	Bolt	M8X35	8X
K	Inset Nut	M8X15	8X
L	Washer	M8.5/20X15	12X
M	Allen key	LG4	2X

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 10 minutes.
Tools Required for Assembly (included): Allen Key

1

2

Step 1

Attach leg frame (A) to Frame seat (D) ,use Bolt (H) and Washer (I),tighten with allen key (M).

Step 2

Tighten Bolt (I) and Insert nut (K) with allen key (M) to attach seat frame (D) and back frame (B), side frame (C).

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 10 minutes.
Tools Required for Assembly (included): Allen Key

3

F
F
G
E
F1

Step 3
Attach cushion seat and cushion back, Side cushion.

4

Step 4
Complete