
ASSEMBLY INSTRUCTIONS


V-WD26-1407


PF035




WARNING !







Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.

PACKAGE CONTENT


Board Identification

Not actual size




BOARD IDENTIFICATION


Not actual size




1 x1




2 x1




3 x1




4 x1




5 x1




6 x2




7 x1




8 x1




9 x6




10 x6




11 x1




12 x1




13 x1




14 x1




15 x6



16 x6













17 x6




18 x6


HARDWARE LIST


 Ø6x33.5mm A x50+5	 Ø15x9.5mm B x50+5	 Ø6x30mm C x38+3	 Ø5x38mm D x10+1
 Ø3.5x12mm E x69+6	 F x12	 Ø6x12mm G x24+2	 Ø3x15 H x4+1
 5/32x10mm I x12	 J x5	 K x6 SET	 Ø4x38mm L x30+3
M1x2 140*19mm  M2x4 Ø16xØ6.5x1mm  M3x2 Ø4x16mm  M		N1x2  Ø6x30 N2x2  Ø4x35 N	 N x1
 CL x6	 CR x6	 DR x6	 DL x6

Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.

1 

2 


3 


The opening must point toward the edge of the board


4 


STEP 1

PF035






CR x 3



CL x 3


Ø3.5x12mm
E x 15

STEP 2









Ø6x33.5mm
A x 2


STEP 3

PF035











CR	x 3





CL	x 3




Ø3.5x12mm	
E	x 18

STEP 4












Ø6x33.5mm	
A	x 6

STEP 5


PF035










STEP 6









CAUTION: Heavy! You may need assistance with this step







STEP 7


PF035





CAUTION: Heavy! You may need assistance with this step







Ø6x30mm	
C	x 2



Ø15x9.5mm	
B	x 2

STEP 8






Ø6x30mm	
C	x 3

Ø15x9.5mm	
B	x 3

STEP 9

PF035




After this step is assembled,
flip it 90 degrees(to next step)

Ø6x30mm	
C	x 3

Ø15x9.5mm	
B	x 3

STEP 10




Ø6x30mm	
C	x 6

Ø5x38mm	
D	x 10

STEP 11


PF035




Ø6x12mm	
G	x 12

F	x 12

STEP 12






Ø6x33.5mm	
A	x 4

STEP 13


PF035




Ø6x30mm	
C	x 2

Ø15x9.5mm	
B	x 2

STEP 14






Ø6x30mm	
C	x 2

Ø15x9.5mm	
B	x 2

STEP 15

PF035






Ø6x12mm

G	x 12

STEP 16




After this step is assembled,
flip it 180 degrees(to next step)




J	x 5


STEP 17


PF035



STEP 18









Ø6x33.5mm


A	x 6


STEP 19

PF035












STEP 20








STEP 21


PF035



Ø6x30mm	
C	x 12


Ø4*38mm	
L	x 30

STEP 22




STEP 23

PF035




x6







Ø15x9.5mm	
B	x 30

STEP 24






x6






Ø3.5x12mm	
E	x 36




DR	x 6





DL	x 6


STEP 25

PF035











STEP 26





STEP 27

PF035




STEP 28






STEP 29


PF035






STEP 31

PF035





FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

· Tighten all bolts and screws again within the first 2 weeks of assembly
· Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

· Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
· Small amount of mild soap can be used if necessary
- **Dry the surface immediately after cleaning.**

⚠ DO NOT use bleach or alcohol detergent to clean the surface.
⚠ DO NOT apply wood treatment on parts made with MDF and PB.
Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.
Make sure to dry the furniture immediately after cleaning