


SMC-MF-1

SMC-MF-4

Assembly Instructions & Care Guide

Illustrations in this guide are for reference only and may differ slightly from the actual product.

CONTENT

Before You Start

Overview ---- 01
Caution ---- 01
Material Specifications ---- 01

Installation Guide

Exploded Views ---- 02
Component Parts ---- 03
Hardware ---- 04
Assembly Directions ---- 05–31
Troubleshoot ---- 32

Usage and Maintenance

Use and Care ---- 33

Other

Help Center ---- 34

Before You Start

Overview

1. Check and ensure you have received all packages and necessary parts.
2. Prepare adequate assembly space. We recommend using pads or cardboard to prevent the floor from scratches.
3. Read the instructions to familiarize yourself with the assembly requirements. Allow sufficient time and have someone available to assist you if needed.
4. Place all hardware on a soft surface for easy identification.
5. The seller is not responsible for any damage or injury caused by improper assembly or use.
6. If you need further assistance, please contact us through runmuservice@gmail.com

Caution

1. Children must not assemble this product. During assembly, keep small parts away from children as swallowing or inhaling them could be fatal.
2. Do not allow children to stand, climb, or play on the product, as it may tip over and cause serious injury.
3. Keep plastic packaging bags away from children to prevent risks of suffocation.
4. Avoid sharp objects and corrosive chemicals to prevent product damage or personal injury.


Material Specifications


Solid Wood

Natural grains, scars, and color variations are inherent in real wood, which contribute to its unique beauty. Slight color changes may occur under different lighting and angles, due to variations in wood grain and light intensity.


Installation Guide

Exploded Views







1. Install the screw rod




2. Tighten the screw rod clockwise




3. Pay attention to tightening the screw rod



4. Installation plate




5. Align the arrow of the eccentric component with the screw rod



6. Pay attention to aligning the arrow of the eccentric part with the screw rod

Component Parts

☐ ① x1




1615 x 632mm

☐ ② x1




996 x 630mm

☐ ③ x1




996 x 630mm

☐ ④ x1




1540 x 332mm

☐ ⑤ x1




1540x 332mm

☐ ⑥ x1




1540 x 332mm

☐ ⑦ x1




1540 x 291mm

☐ ⑧ x1




1540 x 291mm

☐ ⑨ x1




588 x 250mm

☐ ⑩ x1




588 x 250mm

☐ ⑪ x1




550 x 198mm

☐ ⑫ x1




550 x 198mm

☐ ⑬ x1




1199 x 198mm

☐ ⑭ x1




520 x 198mm

☐ ⑮ x1




520 x 198mm

☐ ⑯ x1




1144 x 198mm

☐ ⑰ x1




490 x 198mm

☐ ⑱ x1




490 x 198mm

☐ ⑲ x1




1089 x 198mm

☐ ⑳ x1




470 x 178mm

☐ ㉑ x2




1089 x 235mm

☐ ㉒ x1



1536 x 260mm

☐ ㉓ x1



1536 x 355mm

☐ ㉔ x1



1536 x 355mm

☐ ㉕ x1



720 x 768mm

☐ ㉖ x1



720 x 768mm

Hardware

Ax80 (+8)




Ø6 x 39mm

Bx80 (+8)




Ø15 x 10mm

Cx2



155 x 24mm

Dx8



100 x 70mm

Ex5




Ø80 x 2mm

Fx8



Ø3.5 x 25mm

Gx2




75 x23x20mm

Hx12



H52mm

Ix1




162X55X40mm

Jx6



490mm

Kx4



M7 x 38mm

Lx116 (+10)



Ø3.5 x 14mm

Mx4




Ø4 x 30mm

Nx19 (+1)



M10 x 40mm

Ox6



Px54 (+5)



Ø4 x 14mm

Qx4



Ø3.5 x 18mm

Rx4




Ø4 x 16mm


Install your new product with care, following the instructions step-by-step. Do not skip any steps. Carefully distinguish between left and right components. Do not over-tighten screws or use power tools, as this may damage the product.

Tools You May Need

*You might need a screwdriver (+/-) to complete this assembly.



Persons and Time Needed For Assembly




Assembly Directions


SIIdes Must be Separated Before Assembly.
After Separated,Set Aside Until Needed for Assembly.


Las diapositivas debensepararse antes del montaje.
Despu! s delaseparadi$n,d! jelo a un lado hasta que sea necesario.

Les glissi&res doivent etres! par! es avant tassemblage.
Apr&s las! paration,mettez dec(t! jusqu'au moment deiassemblage.




Step 1: Extend sllde
Extender la dapositiva
Extendre la dapositive





Step 3: RemoveRunner
Quitar el corredor
Enlever le coureur

Step 2: Push Lever Up
Empujar hacia arriba
Lewer le levir



Assembly Directions

Step 1

G x2 

L x6  Ø3.5 x 14mm

I x1 


Step 2


A x20 

Step 3

A x8

N x4






Step 4

J x2

L x8 Ø3.5 x 14mm




As shown in the figure: Drill selftapping for the corresponding holes and assemble the guide rail component J1

Assembly Directions


Step 5

B x8




Step 6

N x8




Step 7




Step 8

B x4



Step 9


B x4



After completing this step, stand the cabinet upright.


Step 10

B x12




Step 11

K x4 




Step 12

A x10 



Step 13

B x10



Step 14

J x2



L x6



Ø3.5 x 14mm

As shown in the figure: Drill self-tapping for the corresponding holes and assemble the guide rail component J2

After completing this step, flip the panel 180°


Assembly Directions

Step 15

A x6


J x2


L x8 Ø3.5 x 14mm




Step 16

B x6








Step 17

H x4


P x8 Ø4 x 14mm



Step 18

J x2

L x6 Ø3.5 x 14mm



As shown in the figure: Drill selftapping for the corresponding holes and assemble the guide rail component J2

After completing this step, flip the panel 180°


Assembly Directions

Step 19

A x6


J x2

L x8 Ø3.5 x 14mm



Step 20


B x6



Step 21

H x4


P x8 Ø4 x 14mm



Step 22

J x2

L x6 Ø3.5 x 14mm




As shown in the figure: Drill selftapping for the corresponding holes and assemble the guide rail component J2

After completing this step, flip the panel 180°


Step 23

A x14




Step 24

A x5




Step 25

B x2




Step 26

B x3




Step 27

B x5




Step 28

B x2



Step 29


B x7



Step 30


H x4

P x8 Ø4 x 14mm



Step 31


A x11



Step 32

After completing this step, flip the panel 180°

B x8




Step 33

B x3

M x4

Ø4 x 30mm




Step 34


O x2

Q x4

Ø3.5 x 18mm




Step 35




Note: Align the tracks for connection.

Step 36



Note: Align the tracks for connection.


Step 37



Note: Align the tracks for connection.

Step 38


N x4



Step 39

E x3

P x18 Ø4 x 14mm



After completing this step, flip the panel 180°


Step 40

G x2

L x4 Ø3.5 x 14mm

C x2

R x4 Ø4 x 16mm




Step 41

O x4


F x8

Ø3.5 x 25mm



Step 42


N x3




Step 43

E x2 


P x12 
Ø4 x 14mm




Step 44

D x8 


L x64  Ø3.5 x 14mm




Step 45




Step 46






Step 47




Step 48




OK


Step 49




Step 50



Step 51



Step 52




Troubleshoot


Product Category	Fault	Cause Analysis	Handing Method
Wood furniture	Door opening is not flexible	The furniture is not leveled	Use items to level the furniture
		The door hinges should be adjusted properly.	Adjust door hinges and apply lubricating oil.
	Inflexible opening of drawer	Overload or deformation	Reduce weight,adjust guide rails, lubricate
	Loose component connection	Loose hinges or screws	The poke part should be coated with an appropriate amount of 502 glue, then re-install or tighten the screws.
	Minor scratches	friction with hard o sharp objects	Use a brush to apply similar pigment ink along wood grain to the scratches, then wipe off the excess.
	Corrosive stains	Accidentally stained with chemical solvents such as nail polish, nail polish remover, ect.	Wipe them with a dry cotton cloth immediately

Possible Issues During Assembly:

- The two boards can't be aligned at he same level.




- Holes on the bards and poles are not aligned, so screws can't be installed.



Recommended Solution:

- Please sightly loosen all screws and adjust the bards. Because the diameter of the holes on the pipes 23 mm lager than that of bots, the position of the boards can be adjusted.



- If it is still doesn't work after adjustment, please contact us for more solutions.

Usage and Maintenance

Use and Care

- Leave it vacant for half a month before use, maintain good ventilation to eliminate any odor.
- Place items steadily, heavier items should be placed at the bottom to avoid tipping over. For high temperature or frozen items, please put a heat-resistant pad underneath.
- Do not directly push or drag hard objects on the furniture to avoid scratching the surface.
- Avoid prolonged exposure to sunlight or heat sources to prevent discoloration or fading.
- Pay attention to moisture prevention to avoid mold. Keep the furniture placed steadily to prevent breakage or loosening.
- Please educate children to stay away from the glass sharp corners of the furniture.
- When opening and closing doors or drawers, handle them gently and check the screws regularly to tighten them.
- Use a soft dry cloth to dust, a slightly damp cloth to clean the surface, avoid abrasive cleaners.

Help Center

Treat your furniture with care and follow the maintenance guidelines. In return, your furniture will provide you with lasting comfort and support. For any additional inquiries or assistance, please do not hesitate to contact us at runmuservice@gmail.com


Inquiry


Assembly issue


Missing parts


Returns&Refunds


runmuservice@gmail.com

We look forward to seeing you again soon.