












ASSEMBLY INSTRUCTIONS




PART LIST

1 x1 	2 x1 
3 x1 	4 x2 
5 x2 	6 x1 
7 x1 	8 x1 














PART LIST

9 x1 	10 x4 
11 x2 	12 x1 

ASSEMBLY INSTRUCTION




PART LIST

A  x21+2	B  x21+2	C  x32+2	D  x12+1	E  x12+1	F  x1
G  x21+2	H  x2	I  x4	J  x8	K  x8	L  x2+1
M  x1	N  x2	O  x2	P  x2	Q  x2	


ASSEMBLY INSTRUCTION

1



A x4


2




B x4


C x4

3




x2






4




Make sure the sliding door is properly inserted into the groove to ensure smooth operation.

5




C x4

6




D x4

7



A x3


8



B x3


C x2

9




A x10


10




C x5

11






12




13




C x5

14




B x5

15




A x4

16




B x4

C x4



Make sure the sliding door is properly inserted into the groove to ensure smooth operation.


18



C x8

D x8


19





E x12

F x1

20








J x8

K x8


21




N x2

Q x2

22







G x21

L x2

M x1

23





O x2 P x2

24

