INSTRUCTION MANUAL

MODEL:
HW-1110

ASSEMBLY GUIDE



Congratulations on your new chair!

Before enjoying your comfortable chair, ***please follow these instructions and the important safety information*** to ensure a smooth assembly. While you can assemble it alone, ***having a second person will make it even easier***.


Before you begin, please check for any missing parts. If there are any issues, please email us and we will resolve your issue immediately.

PACKAGE LIST




ASSEMBLY INSTRUCTION

Step 1: Attach the Base Legs (H) to the Base Center (L) using five M6x16mm Bolts (a). Tighten securely with the Allen Key.




Step 2: Insert the five Casters (I) into the ends of the Base Legs (H). Insert the Gas Lift (G) into the center of the 5-Star Base (L).




Step 3: Attach the Footrest Guide Fasteners (M) to the bottom of the Seat Cushion (C) using four M6x25mm Screws (c).

Tips: The base is now installed.




Step 4: Insert the component (F) into component (M) and secure it with 2pcs screws M6*16mm (a).




Step 5: Attach the seat plate (E) to the seat cushion (C) with 4pcs screws M6*20mm (b).

Tips: The seat cushion is now installed.


Note : Do not tighten screws completely until all the screws are fixed in the correct positon




Step 6: Position the Lumbar Support (K) on the front of the Chair Back (B). Secure it from the back using two M6x16mm Screws (a), then snap on the Lumbar Support Covers (P).




Step 7: Attach the chair back (B) to the seat cushion (C) with 3pcs screws M8*20mm (e).




Step 8: Place the armrests (D) into position, snap components (g) and (f) together, and secure the armrest with 1pc screw M6*25mm (c). Repeat on the other side.



Step 9: Cover the screw holes with component (h). Then, place the assembled upper chair onto the base section.



Step 10: Attach the headrest (A) and coat hanger (J) to the chair back (B) with 2pcs screws M6*30mm (d) , then cover with component (N).
To use the massage function, simply connect the massage connection cable (O) to the wire on the lumbar support. Assembly complete!



CAUTION:
Make sure all bolts and screws are fullytightened before using chair Lubricate allmoving parts and tighten all bolts / screws every 6 months or whenever needed.

Before You Get Started

Having a friend to help makes assembly easier

Mind the important safety information

Contact us if you have any issue


service@jurkosp. vip

INSTRUCTION MANUAL

MODEL:
HW-1110

INSTRUCTIONS FOR USE

1 . Seat Height : Paddle-shaped lever on the right side




To raise:
Relieve your weight from the seat and lift the lever up.

To lower:
While seated, lift lever up.

* At the proper height, your feet should rest flat on the floor.

2 . Reclining Angle Adjustment: lever under the left side of the seat



To recline:
While seated, lift the lever up to adjust the backrest angle up to 155°.

To lock the angle:
Once at your desired angle, press the lever down to lock it into place.

* Use the left lever to customize and lock your preferred reclining angle for maximum comfort.

3 . Footrest Function: under the seat cushion




To use the footrest:
Pull the footrest out from under the seat, and flip it outward.

To retract the footrest:
Flip the footrest back inward completely, then push it all the way back under the seat.

* Always ensure the footrest is fully flipped back before pushing it in to prevent any damage.

4 . Multi-functional armrest



Easily flip-up arms saving space

SAFETY AND MAINTENANCE

- Do not stand on the chair, Do not use the chair as stepladder.
- Use this product for seating one person at a time.
- Do not use the chair unless all bolts and screws are firmly secured.
- Avoid contact with sharp objects to prevent puncturing the fabric.
- Every 6 months, check all bolts and screws to ensure they are tight.
- To clean, spot clean only using a damp towel and mild cleaner, first test on a small, obscure area of fabric.

SAFETY INFORMATION



LIMITED WARRANTY

We promise to repair or replace a new chair that is found to be defective in material or workmanship within one (1) year from the date of original purchase so long as you, the original purchaser, still owns it. This is your sole and exclusive remedy. This warranty is subject to the provisions below.

EXCLUSIONS:

This warranty does not apply and no other warranty applies to:

- Normal wear and tear, which are to be expected over the course of ownership.
- Misuse, abuse or excessive use of the product.
- Modifications or attachments to the product that are not approved by us.
- Products that were not installed, used, or maintained in accordance with product instructions and warnings.
- Products used for rental or commercial purposes.
- Damage caused by the carrier in-transit is handled under separate terms.

Seating Usage: Normal use for seating is identified as the equivalent of a single shift, forty- (40) hour workweek. If the product is used for multi-shift operations or exceeds normal usage limits, the warranty period will be reduced proportionally.

Some retailers might have custom models imported direct from the factory and therefore are not supported by our local service team because we don't have the correct parts, please contact your retailer directly for support. If you have any question about that we will be happy to assist and identify those items.

RETURN POLICY:

We adopt a 30 days return policy which means that all products purchased from our authorized store may be returned to us within the timeframe. You need to contact us within 30 days after the product (s) came into your possession and the product (s) must be retumed to us without any undue delays.

Returned products must be returned in the same condition as they were sent and they must be sent in its original packaging.

If the product is not faulty, (i.e. if you change your mind or if you are unhappy with the product for some other reason), the cost of shipping will fall on you. And it is your responsibility that the package arrives safely to us so we recommend that you use a courier service where it is possible to track the shipment.

If the product is faulty when you receive it please contact us and we will help you out.

We reserve the right to give a partial refund in cases when the product (s) is not in an unused condition, is damaged or have missing parts not due to our error.

HOW RETURNS WORK:

Contact us directly via our customer service email (service@jurkosp.vip) with your Amazon Order ID as proof of purchase.

We will then get back to you as soon as possible with information about where to send the product (s).

As soon as we have received the product (s) and made an inspection we will inform you of our decision.

If a refund is approved we will automatically credit the refund to your credit card or original method of payment.

CAUTION:
Make sure all bolts and screws are fullytightened before using chair Lubricate allmoving parts and tighten all bolts / screws every 6 months or whenever needed.

Before You Get Started

Having a friend to help makes assembly easier

Mind the important safety information

Contact us if you have any issue

service@jurkosp. vip