




Bed Frame with LED lights User Manual

Disassembly Diagram

The installation would be easier if completed by two people.






Accessories

A




×2

B




×1

C




×1

D




×1

E




×2

F



×1

G




×3

H



×10

I




×1

J




×1

K



×1


L



×1


Accessories

1




M8×40mm ×4

2




M6×60mm ×13

3




M6×28mm ×12

4




M6×18mm ×4

5




M6×10mm ×12

6



×4

7




×8

8




4×4mm ×2

9




×1

10




×1

11



Ø3.5×12mm ×2


12




×1

step 1

Install the charging station 10 on the wooden board D with screws 11 .







8 ×1pc 10 ×1pc 11 ×2pcs


step 2

Secure the metal tube (C) , metal frame (L) , wooden platform (I) and wood board (D) between the frame (A) with screws (2) .



Please tighten the bolts to 80% first, and tighten all bolts 100% after all parts are assembled.






(2) ×10pcs




(8) ×1pc

step 3

Fix the wood board (K) on the metal platform (from back) with screws (5)
And fix the metal frame (L) on the wooden platform (I) with screws (5)



turn to the back side




(5) ×12pcs


(8) ×1pc


step 4


Install the light strip 9-1 on the back of the wood top board B

Installing the light strip










9 ×1pc

step 5

Secure the wood top board B on the metal frame with screws 3






3 ×6pcs



8 ×1pc


step 6

Unfold the bed edge frame (E)



step 7

Fix the bed edge frame (E) on the bed frame with screws (1) & (4) and washer (7) and nut (6)





Please use 2 pcs of ⑧ in both side to fix the screw ④ and nut ⑥

1 ×2pcs 4 ×2pcs 6 ×2pcs 7 ×4pcs 8 ×2pcs

step 8

Fix another side bed edge frame (E) on the footboard (F) with screws (1) & (4) and washer (7) & nut (6)






1 ×2pcs 4 ×2pcs 6 ×2pcs 7 ×4pcs 8 ×2pcs

step 9

Secure the metal tube G between the frame with screws 3






3 ×6pcs





8 ×1pc

step 10

Unfold the frame J








step 11

Fix the metal tube (G) on the frame (J) with screws (2) .

To prevent friction noise, unroll part 12 and fit it on part J , The lenght of part 12 can cut as you will.






2 ×3pcs 8 ×1pc 13 ×1pc

step 12

Embed the metal stick (H)




×10

No tool is needed, just press part H firmly into the slot


step 13

Remote Control



step 14

Installation completed



Customer Service

1-Year Warranty

We guarantee your product is free from defects in product material and work manship for one(1)year starting from the date of purchase during normal use of household conditions. If your appliance fails within the limited warranty period, we will arrange a new replacement free of charge, and cover all the shipping costs.

Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately at our support email. It doesn't matter if the product has been installed, our customer support team will respond within 24 hours and assist you quickly and efficiently. Themost efficient way to confirm your problem with us is to attach a video or picture illustrating your product issue.

Problems You May Encounter

PART	PROBLEM	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us, and we will get back to you within 24 hours. Or, you can reach USvia after -sales email
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Board Surface	Board Surface is broken, scratched or lack of some screw holes.	You can contact us, and we will get back to you within 24 hours. Or, you can reach USvia after -sales email
	The screw holes that on the board and steel frame don't line up.	1. Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjusting board and steel frame until the screw holes are lined up,then tighten all the screws.
	The wood board is uneven or not tight that has gaps after being assembled.	You can contact us, and we will get back to you within 24 hours. Or, you can reach USvia after -sales email
Steel Frame	The steel frame is bent, broken, painted, rusted or damaged.	You can contact us, and we will get back to you within 24 hours. Or, you can reach USvia after -sales email
	The bed frame is unstable after being assembled.	1.Check if the screws are tightened. 2. Read through out the manual, check are there any parts insalled incorrecly or missing assembled. 3. If your problem still can't be solved, please feel free to contact us.