
Assembly Instructions



Dining Table


Contact Us

We're here to help you.

Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.




We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



AVOID SCRATCHES

In order to avoid scratching, this furniture should be assembled on a soft surface, such as a rug.






⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge.
Contact us for a free replacement if you encounter any damaged or missing parts.


Parts List



❶ 2 pcs



❷ 1 pc




❸ 2 pcs




❹ 6 pcs



❺ 6 pcs








❻ 2 pcs



❼ 2 pcs


Hardware List


A	X36+1	B	X18+1	C	X12+1	D	X18+1
							
M6X20 mm		M6X30 mm		M6X55 mm		φ7X47mm	

E	X4+1	F	X1	G	X8+1	H	X4
							
Ø10X50 mm		M4X55 mm		M6X15 mm		40X20 mm	

1

screw down 100%







A	X22	F	X1
			
M6X20 mm		M4X55 mm	

2


screw down 100%







A	X14
	
M6X20 mm	

3



D	X18
	
Ø7X47mm	


4



E	X4
	
Ø10X50 mm	

5


screw down 100%




G	X8	H	X4
			
M6X15 mm		40X20 mm	

6


screw down 100%



C	X12
	
M6X55 mm	

7

screw down 100%



B	X18
	
M6X30 mm	

Thank you for your support!

