Fireplace Mantel

PLEASE READ THIS MANUAL THROUGHLY BEFORE USING THIS APPLIANCE



Before You Start

⚠ Please read all instructions carefully.

⚠ Retain instructions for future reference.

⚠ Separate and count all parts and hardware.

⚠ Read through each step carefully and follow the proper order.

We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

⚠ Always place the product on a flat, steady and stable surface.

⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.


Bluetooth Speaker
Air Vent
Bluetooth Speaker
Touch Button


AC

BUTTON CONTROLS

POWER BUTTON: Short press to turn on/off.

FLAME COLOR BUTTON: Short press to change 13 flame colors (d1-d13 mode);
Long press to adjust flame brightness (L1-L5 mode).

AIR OUTLET BUTTON: First press to turn on the ambient air (FF mode);
Second press to turn on heating (H2 mode).

TIMER BUTTON: Short press to activate timer (0H); press repeatedly
to set timing from 1 to 9 hours.

ROMOTE CONTROLS

Power Button: Short press to turn on/off.

Auto Button: Short press to automatically switch
13 flame colors ("13" mode);
press the Flame Color Button to pause auto-mode.

Flame Color Button: Short press to change
13 flame colors (d1-d13 mode)

Ambient air Button: Short press to turn on/off
ambient air mode (FF or 0F)

Heating Button: Short press to turn on/off heating
mode(H2 or 0F)

Timer Button: Short press to activate timer (0H);
press repeatedly to set timing from 1 to 9 hours.

Brightness Button: Shot press to adjust flame brightness.

PRODUCT INFORMATION

Product Name: Electric Fireplace

Voltage 120V AC 50/60Hz

Flame Power: 26W/m

Heating Power: 1500W

ASSEMBLY INSTRUCTION

A 4PCS	B 8PCS	C	D 1PCS	E 1PCS
				

INSTALLATION

1.Remove the screws, hardware, and glass panel;

2.Place the crystals inside the fireplace;

3.Reattach the glass panel, then secure all hardware and tighten the screws.

