
ERGONOMIC LIFT CHAIRS FOR ELDERLY

ASSEMBLY INSTRUCTIONS

YS231132 SERIES



ATTENTION

THANKS FOR CHOOSING OUR PRODUCTS!


1. **This swing comes in 2 boxes, please check the part list carefully to make sure you've received all the parts.**

2. **If there're any missing parts, please contact us with the part # and quantity, we will send them to you ASAP.**




3. **If there're any damaged parts, please contact us with clear pictures or video, we will offer you the best solution after confirming it.**

Assembly Instruction

Parts List BOX A

A	B
 Chair Base	 Left Armrest
1 pc	1 pc

Parts List BOX B

C	D	E	F
 Power Cord	 Remote Control	 Power Source	 Connection Wire
1 pc	1 pc	1 pc	1 pc
G	**I**	**J**	
 Anti-fall Bracket	 Backrest	 Right Armrest	
2 pcs	1 pc	1 pc	

NOTE

1. If one or some screws are fully tightened during assembly, the other screws may not be aligned with screw holes. 70% tighten before fastening all screws. Allen wrench is recommended instead of an electric drill.
2. If some screws are not aligned with holes during assembly, please loosen all the other screws to 70% and continue the assembly process.
3. If the items is not stable, please loosen all the screws, adjust it on a flat ground and tighten all the screws.


Assembly Instruction

Step 1



A*1


B*1


J*1



Assemble left and right armrests into the slots on the chair base.




Noted: The cup holder is facing outward.

Assembly Instruction


Step 2



I*1



Assemble backrest into theslots on the chair base.




Note: If the armrest or back shakes after assembly, please knockdown and assemble again, and make sure that all the slots areproperly aligned.

Assembly Instruction

Step 3



G*2




Attach brackets to the base with wing nuts.

Assembly Instruction

Step 4


C*1



D*1



Note: Two same color wires connect.

Power source(E)

Note: Need arrows be aligned for No.4 wire connects.



No.1 and No.2 wire connect with the backrest and chair base.- No.3 wire connects with backrest and power cord(C).No.4 wire connects with backrest and remote control(D)

Assembly Instruction


Step 5




E*1



F*1








Note: All wires cannot put under feet.

No.5 wire connect with the motor and armrest with control panel.
No.6 wire connect with the motor and power source(E).
Note: Plug power cord and power source into outlet, then you canuse all function.


How to recline

Warning: Do not sit or hit the footrest after lift up.




How to remove the chair

Please note that you need to take apart the backrest before removing the arms.




1. Force apart the buckles while take the backrest out from the arms.



2.Then pull out the arms from the base.

Note: Please pull out the armrests from the middle of the armrests.

How to use remote control



POWER:
Turn on/off remote control.

HEAT:
Turn on/off heat function for lumbar part only.

INTENSITY:
Control massage function from low or high.

MODE:
Choose one massage mode you like (pulse, press, wave, auto, normal).

You can choose 1-4 massage parts (back, lumbar, thighs, legs) to enjoy.

You can choose 3 modes time setting as you like:15min, 30min, 60min.

CONTACT US

If you order products on our store:

Please contact our service team if you need help. The service email isxinshenga202311@163.com.

(Guaranteed response within 24 hours)

If you order our products on Amazon/Walmart/Wayfair etc. Log in Amazon/Walmart/Wayfair etc. to contact the seller. Order>Sold By>Contact Seller

WARRANTY

So glad you have completed the assembly and can enjoy it. If you are satisfied with our products, thank you for showingyour favored ERGONOMIC LIFT CHAIRS FOR ELDERLY to your around.

Customer Service:

Any problem with the product or shipping issue, please feel free to contact us, we will try our best to serve and help.